

FSMH13151SM STEAM MOP

Technical Data

		FSMH13151SM
Voltage	V_{ac}	220-240
Power	W	1300
Tank Capacity	ml	500
Weight	kg	2.8

Intended use

Your BLACK+DECKER™ FSMH13151SM steam mop has been designed for sanitising and cleaning sealed hardwood, sealed laminate, linoleum, vinyl, ceramic tile, stone and marble floors. This appliance is intended for indoor household use only.

Safety Instructions



Warning! Read all safety warnings and all instructions. Failure to follow the warnings and instructions listed below may result in electric shock, fire and/or serious injury.



Warning! When using main-powered appliances, basic safety precautions, including the following, should always be followed to reduce the risk of fire, electric shock, personal injury and material damage.

- ◆ The intended use is described in this manual. The use of any accessory or attachment or the performance of any operation with this appliance other than those recommended in this instruction manual may present a risk of personal injury.
- ◆ Retain this manual for future reference.

Using your appliance

- ◆ Do not direct steam at people, animals, electrical appliances or electrical outlets.
- ◆ Do not expose to rain.
- ◆ Do not immerse the appliance in water.
- ◆ Do not leave the appliance unattended.

- ◆ Do not leave the appliance connected to an electrical outlet when not in use.
- ◆ Never pull the power lead to disconnect the appliance from the socket. Keep the appliance lead away from heat, oil and sharp edges.
- ◆ Do not handle steam cleaner with wet hands.
- ◆ Do not pull or carry by cord, use cord as a handle, close door on cord, pull cord around sharp corners or expose cord to heated surfaces.
- ◆ Do not use appliance in an enclosed space filled with vapour given off by oil-base paint thinner, some moth-proofing substances, flammable dust, or other explosive or toxic vapours.
- ◆ Check the type of floor with the manufacturer.
- ◆ Do not use on leather, wax polished furniture or floors, synthetic fabrics, velvet or other delicate, steam-sensitive materials.



Warning! Do not use on unsealed wood or unsealed laminate floors. On surfaces that have been treated with wax or some no wax floors, the sheen may be removed by the heat and steam action. It is always recommended to test an isolated area of the surface to be cleaned before proceeding. We also recommend that you check the use and care instructions from the floor manufacturer.

- ◆ Never put descaling, aromatic, alcoholic or detergent products into the steam cleaner, as this may damage it or make it unsafe for use.
- ◆ If the home circuit breaker activates while using the steam function, discontinue product use immediately and contact the customer support centre. (Beware of the risk of electrical shock.)
- ◆ The appliance emits very hot steam to sanitize the area of use. This means that the steam head, cleaning pads and carpet attachment get very hot during use.

Caution! Always wear suitable shoes when using your steam mop and when changing the accessories on your steam mop. Do not wear slippers or open toed footwear.

- ◆ The lid may become hot during use.
- ◆ Steam may escape from the appliance during use.
- ◆ Care should be taken when using this appliance. DO NOT touch any parts which may become hot during use.
- ◆ Switch the appliance off and return the handle to the upright position before removing the water tank.
- ◆ If steam is observed escaping from the body of the hand held steam cleaner, switch off and disconnect the unit from the mains supply, allow to cool. Contact your nearest authorised repair agent. Do not continue to use the appliance.

After use

- ◆ Unplug the appliance and allow to cool before cleaning.
- ◆ When not in use, the appliance should be stored in a dry place.
- ◆ Children should not have access to stored appliances.

Inspection and repairs

- ◆ Unplug the appliance and allow to cool before performing any maintenance or repairs.
- ◆ Before use, check the appliance for damaged or defective parts. Check for breakage of parts, damage to switches and any other conditions that may affect its operation.
- ◆ Regularly check the power lead for damage.
- ◆ Do not use the appliance if any part is damaged or defective.
- ◆ Have any damaged or defective parts repaired or replaced by an authorized repair agent.
- ◆ Never attempt to remove or replace any parts other than those specified in this manual.

Safety of others

- ◆ This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and

understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

- ◆ Children should be supervised to ensure that they do not play with the appliance.

Residual risks

Additional residual risks may arise when using the tool which may not be included in the enclosed safety warnings. These risks can arise from misuse, prolonged use etc.

Even with the application of the relevant safety regulations and the implementation of safety devices, certain residual risks can not be avoided. These include:

- ◆ Injuries caused by touching any moving parts.
- ◆ Injuries caused by touching any hot parts.
- ◆ Injuries caused when changing any parts or accessories.
- ◆ Injuries caused by prolonged use of the appliance. When using any appliance for prolonged periods ensure you take regular breaks.

Electrical safety



Warning! This product must be earthed. Always check that the power supply corresponds to the voltage on the rating plate.

Power plugs must match the outlet. Never modify the plug in any way.

Unmodified plugs and matching outlets will reduce risk of electric shock.

- ◆ If the supply cord is damaged, it must be replaced by the manufacturer or an authorised BLACK+DECKER Service Centre in order to avoid a hazard.

Extension cables & Class 1 product

- ◆ A 3-core cable must be used as your appliance is earthed and of Class 1 construction.

Labels on appliance

The following pictograms along with the date code are shown on the appliance.



CAUTION Hot Steam
Danger of scalding.



Water dripping when used upside down



Steam escapes from all sides



Do not leave unsupervised with young children



Wash at 60°C. Do not use bleach or fabric softener



Caution! Hot surface

Features

This appliance includes some or all of the following features.

1. On/off switch
2. Smart select dial
3. Hand held steam unit handle
4. Filler cap
5. Hand held steam unit
6. Hand grip
7. Top cable tidy hook
8. Main handle

- 9. Bottom cable tidy hook
- 10. Hand held steam unit release button
- 11. Main body
- 12. Floor cleaning head
- 12a. Steam burst floor cleaning head
- 13. Floor cleaning pad
- 14. Floor cleaning pad release tab
- 15. Hanging Bracket
- 16. Steam hose
- 16a. Hose release button
- 17. Steam nozzle
- 18. Squeegee accessory
(for use on shower screens / glass / mirrors / clothing / upholstery)
- 19. Steam burst brush unit
- 19a. Steam burst wire brush
(for use on BBQ / ovens)
- 19b. Steam burst brush
(for use on BBQ / ovens / oven hobs / taps / grout)
- 19c. Steam burst wide brush
(for use on larger work surfaces)
- 20. Delta head
- 20a. Flat surface cleaning pad
- 21. Adjustable nozzle
- 22. SteaMitt™
- 23. SteaMitt™ hose
- 24. SteaMitt™ cleaning pad

- ◆ Place a cleaning pad (13) on the floor with the velcro 'loop' side facing up.
- ◆ Lightly press the steam mop down onto the cleaning pad (13).

Note: This unit may be supplied with a standard floor cleaning head (12) or a steam burst cleaning head (12a). In either case use these instructions to fit a cleaning pad.

Caution! Never leave the steam mop in one spot on any surface for any period of time. Always place the steam mop with the handle (8) supported in the upright position when stationary and make sure the steam mop is turned off when not in use.

Removing a cleaning pad

Caution! Always wear suitable shoes when changing the cleaning pad on your steam mop.

Do not wear slippers or open toed footwear.

- ◆ Return the handle (8) to the upright position and turn the steam mop 'OFF'.
- ◆ Wait until the steam mop cools down (approximately 5 minutes).
- ◆ Lift the steam mop away from the cleaning pad freeing it from the velcro fastening.

Caution! Never leave the steam mop in one spot on any surface for any period of time.

Always place the steam mop with the handle (8) supported in the upright position when stationary and make sure the steam mop is turned off when not in use.

Filling the water tank (Fig. P)

Note! Fill the water tank with clean tap water (Do not use any additives or chemicals).

Note! In areas of hard water, the use of de-ionised water is recommended.

- ◆ Open the filler cap (4) by flipping it up.
- ◆ Fill the water tank with water (Do not use any additives or chemicals).

Warning! When filling, detach from main unit and maintain in a horizontal position.

Warning! Your water tank has a 0.5 litre capacity. Do not over fill the tank.

- ◆ Close the filler cap (4).

Note! Ensure the filler cap is firmly secured.

Attaching the hose and accessories to the hand held steam cleaner (Fig. G - N)

Warning! Inspect the seal between the connection point on the hand held steam cleaner (5) and the steam hose (16) before each use. If the seal malfunctions or is damaged, please contact your nearest authorised repair agent. Do not use the appliance.

Warning! The unit should be switched off before the hose is

Assembly



Warning! Before attempting any of the following instructions, make sure that the appliance is switched off and unplugged and the appliance is cold and does not contain any water.

Attaching the handle (Fig. A)

- ◆ Slide the bottom end of the handle (8) into the top end of the steam mop body (11) until it clicks into place.

Attaching the hand held steam cleaner (Fig. B)

- ◆ Holding the back of the steam mop body (11) push the hand held steam cleaner (5) firmly into the steam mop body (11) making sure it sits correctly over the interface (11a) and clicks securely into place.

Removing the hand held steam cleaner (Fig. B)

- ◆ Push the release button (10) on the main body (11) and lift the hand held steam cleaner (5) off the interface (11a) and away from the main body (11).

Attaching a cleaning pad (Fig. C)

Replacement cleaning pads are available from your BLACK+DECKER dealer.

fitted.

Attaching the hose

- ◆ Press the steam hose release button (16a) on the steam hose (16).
- ◆ Connect the steam hose (16) to the hand held steam cleaner (5) and release the steam hose release button (16a) making sure it clicks into place.

Important! Ensure that the steam hose (16) is securely connected to the hand held steam cleaner (5). If steam escapes from the joint, the hose is incorrectly fitted. Switch off, allow the unit to cool then remove and refit the hose.

Attaching accessories (Fig H)

- ◆ Align the lugs on the steam nozzle (17) with the recesses on the accessory.
- ◆ Press the accessory onto the steam nozzle (17) and twist anti-clockwise until the accessory clicks into place.

Important! All accessories, apart from the SteaMitt™ (22) which has its own hose and connector (23), must be attached to the steam hose (16) for use.

Removing the hose and accessories

Warning! The steam hose (16), Steam nozzle (17) and accessories become hot during use. Allow the unit and all accessories to cool before attempting to remove.

Removing an accessory

- ◆ Twist the accessory clockwise then pull away from the hose (16).

Removing the hose

- ◆ Press the steam hose release button (16a) on the steam hose (16) and pull away from the hand held steam unit.

SteaMitt™

Your BLACK+DECKER™ SteaMitt™ has been designed for sanitising and cleaning tiles, work tops, kitchen surfaces and bathroom surfaces. This appliance is intended for indoor household use only.

Attaching the SteaMitt™ hose to the hand held steam unit

Warning! Inspect the seal on the steam nozzle and hose before each use. If the seal is missing or damaged then please contact your nearest authorised repair agent. **Do not use the appliance.** Inspect the seal on the SteaMitt™ and hose. If the seal is missing, damaged or any steam is escaping then please contact your nearest authorised repair agent.

Do not use the appliance. Ensure there is no blockage or impedance in the SteaMitt™ hose or attachment hose. If any are detected then please contact your nearest authorised

repair agent. **Do not use the appliance.**

Fitting a cleaning pad to the SteaMitt™ (Fig. K)

Warning! Ensure there is no blockage or impedance in the steam release vents. If any are detected then please contact your nearest authorised repair agent. **Do not use the appliance.**

- ◆ Fit the cleaning pad (24) to the SteaMitt™ (22) by attaching the 'loop' velcro strips (24a) on the upper side of the cleaning pad, to the 'hook' velcro pads (22a) on the underside of the SteaMitt™ (4). Press down firmly.

Warning! The SteaMitt™ should not be used without fitting a cleaning pad.

⚠ **Warning!** Always use the SteaMitt™ as shown in figure M, with your hand inside the protective glove.

⚠ **Warning!** Never attempt to use the SteaMitt™ by gripping it externally as shown in figure N. This will result in scalding.

⚠ **Warning!** Avoid using the SteaMitt™ in tight corners as shown in figure O.

⚠ **Warning!** Should a problem occur during use, use the quick release tab to quickly remove the SteaMitt™ from your hand as shown in figure P.

⚠ **Warning!** Do not use the SteaMitt™ on cold glass, such as windows as damage may be caused by the sudden change in temperature.

⚠ **Warning!** Never point or direct the mitt at yourself or any other person.

Note: It is recommended that the SteaMitt be used in setting 1 to avoid the pad becoming too wet.

Use

Important! This unit will kill 99.9% of bacteria and germs when used in accordance with the instructions in this manual and with the micro fibre pads fitted and a continuous run time of 90 seconds.

Switching on and off

- ◆ To switch the appliance on, press the ON/Off switch (1). It takes approximately 15 seconds for the steam mop to heat up.
- ◆ To switch the appliance off, press the ON/Off switch (1).

Note: always have your hand inside the SteaMitt™ before you press the steam button.

Caution! Never leave the steam mop in one spot on any surface for any period of time.

Always place the steam mop with the handle (8) supported in the upright position when stationary and make sure the steam mop is turned off when not in use.




Caution! Always empty the steam mop after use.

Note! When first filled or after running dry, it can take up to 45 seconds for steam to be produced.

Smart select Technology (Fig. Q)

This steam mop is fitted with an Smart select dial (2) which shows various cleaning applications. They are used to select the correct operating mode for your particular cleaning operation.

Using Smart select, choose from one of the following applications by turning the Smart select dial (2) until the required setting is selected.

Setting	Mop	Hand held
	Wood/Laminate	Low steam flow ●
	Tiles/Vinyl	Medium steam flow ● ●
	Stone/Marble	High steam flow ● ● ●

The steam mop will select the correct volume of steam required for your particular cleaning operation.

Note: Always check you are using the correct setting before using your steam mop.

Steam Burst (Fig. C1)

The floor head (12a) is equipped with a steam burst pedal to aid in the removal of stubborn marks and stains.

- ◆ During use, press the steam burst pedal to apply extra cleaning power.
- ◆ To revert back to normal setting press the pedal again.

Hints for optimum use

General

Caution: Never use the steam mop without first attaching a cleaning pad.

- ◆ Always vacuum or sweep the floor before using the steam mop.
- ◆ The easiest way to use the appliance is to tilt the handle to a 45° angle and clean slowly, covering a small area at a time.
- ◆ Use water only with no additives or chemicals with your steam mop. To remove stubborn stains from vinyl or linoleum floors, you can pre-treat with a mild detergent and some water before using the steam mop.

Steam Cleaning with the mop

- ◆ Fit hand held steam cleaner (5) to the steam mop body (11)
- ◆ Place a cleaning pad (13) on the floor with the velcro 'loop' side facing up.

- ◆ Lightly press the steam mop down onto the cleaning pad (13).
- ◆ Connect the steam mop to the mains.
- ◆ Press the ON/OFF button (1). It takes approximately 15 seconds for the steam mop to heat up.
- ◆ Turn the Smart select dial (2) until the required setting is reached. After a few seconds steam will start to come out of the steam head.

Note! When first filled or after running dry, it can take up to 45 seconds for steam to be produced.

- ◆ It takes a few seconds for steam to enter the cleaning pad. The steam mop will now glide easily over the surface to be sanitized/cleaned.
- ◆ Push and pull the steam mop slowly across the surface to thoroughly steam clean each section.
- ◆ When you have finished using the steam mop, return the handle (8) to the upright position, making sure that it is supported and turn it 'OFF'. Wait until the steam mop cools down (approximately five minutes).

Caution! It is important to monitor the water level in the water tank. To refill the water tank and continue to sanitize/clean stand the mop upright making sure that the handle is supported and turn the steam mop 'OFF'. Unplug the unit from the electrical wall outlet, and refill the water tank.

Caution! Never leave the steam mop in one spot on any surface for any period of time. Always place the steam mop with the handle (8) supported in the upright position when stationary and make sure the steam mop is turned off when not in use.

After use

- ◆ Turn the Smart select dial (2) to the OFF position.
- ◆ Wait until the steam mop cools down.
- ◆ Unplug the steam mop from the electrical wall outlet.
- ◆ Empty the water tank.
- ◆ remove the cleaning pad (13) and wash it ready for next use (take care to follow the wash care instructions printed on the cleaning pad).
- ◆ Wrap the supply cable around the cable tidy hooks (7 and 9).
- ◆ There is a hanging bracket (15) built into the hand grip (6) which allows your steam mop to be hung from a suitable hook on the wall. Always ensure that your wall hook is capable of supporting the weight of the steam mop safely.

Hand held steam cleaning

Warning! Maintain the unit in a horizontal position during use.

- ◆ Attach the required accessory.
- ◆ Connect the hand held steam cleaner to the mains.
- ◆ Press the ON/OFF button (1). It takes approximately 15 seconds for the steam mop to heat up.
- ◆ Turn the Smart select dial (2) until the required setting is reached. After a few seconds steam will start to come out

of the steam head.

Note! When first filled or after running dry, it can take up to 45 seconds for steam to be produced.

- ◆ When you have finished using the hand held steam cleaner turn the Smart select dial (2) to the OFF position. Turn the unit OFF by pressing the ON/OFF button (1) and disconnect from the mains supply. Wait until the unit cools down before storing (approximately five minutes).

Accessories

The performance of your appliance depends on the accessory used. BLACK+DECKER accessories are engineered to high quality standards and designed to enhance the performance of your appliance. By using these accessories you will get the very best from your equipment.

Troubleshooting

If your appliance seems not to operate properly, follow the instructions below. If this does not solve the problem, please contact your local BLACK+DECKER repair agent.

Problem	Step	Possible solution
The steam mop is not turning on	1.	Check the unit is plugged in at the wall socket.
	2.	Check the unit is switched on using the ON/OFF switch (1)
	3.	Check the fuse in the plug.
The steam mop is not producing steam	4.	The steam mop will only produce steam if the hand held steam cleaner (5) is correctly docked into the main body (11) or the steam hose is fitted or the Smart select is turned to ON
	5.	Check that the water tank is full. Note: When first filled or after running dry it can take up to 45 seconds for steam to be produced.
	6.	Check steps 1, then 2, then 3
The steam mop stops producing steam during use	7.	Check steps 4, then 5, then 3
The steam mop is producing too much steam during use	8.	Turn the Smart select dial (2) anti-clockwise to reduce the amount of steam being produced
The steam mop is producing too little steam during use	9.	Turn the Smart select dial (2) clockwise to increase the amount of steam being produced
No steam is being produced from the hand held steam cleaner	10.	Check that the Smart select dial (2) is at the ON position
	11.	Check steps 5, then 1, then 2, then 3
The hand held steam cleaner is producing too little steam during use	12.	Turn the Smart select dial (2) clockwise to increase the amount of steam being produced
	13.	Check step 5
The hand held steam cleaner is producing too much steam during use	14.	Turn the Smart select dial (2) anti-clockwise to reduce the amount of steam being produced
The accessories keep falling off the unit	15.	Refer to the assembly chapter for correct fitting instructions of all parts and accessories
Steam is escaping from unexpected areas of the unit	16.	Refer to the assembly chapter for correct fitting instructions of all parts and accessories

Problem	Step	Possible solution
Where can I get further information/accessories	17.	www.blackanddecker.co.uk/steam mop www.blackanddecker.ie/steam mop

Maintenance and cleaning

Your BLACK+DECKER corded appliance has been designed to operate over a long period of time with a minimum of maintenance. Continuous satisfactory operation depends upon proper appliance care and regular cleaning.

Warning! Before performing any maintenance or cleaning on corded appliances switch off and unplug the appliance.

- ◆ Wipe your appliance over using a soft damp cloth.
- ◆ For stubborn marks you can use a mild solution of soap and water to dampen your cloth.

Care of the cleaning pads

Wash care instructions - No fabric conditioner - Allow to dry fully before re-use.

Caution! Follow the cleaning instructions printed on the label of the cleaning pad.

Protecting the environment



Separate collection. Products and batteries marked with this symbol must not be disposed of with normal household waste.

Products and batteries contain materials that can be recovered or recycled reducing the demand for raw materials. Please recycle electrical products and batteries according to local provisions. Further information is available at www.2helpU.com

Service Information

BLACK+DECKER offers a full network of company-owned and authorized service locations throughout Asia. All BLACK+DECKER Service Centers are staffed with trained personnel to provide customers with efficient and reliable product service.

Whether you need technical advice, repair, or genuine factory replacement parts, contact the BLACK+DECKER location nearest to you.

NOTE

- ◆ BLACK+DECKER's policy is one of continuous improvement to our products and, as such, we reserve the right to change product specifications without prior notice.
- ◆ Standard equipment and accessories may vary by country.
- ◆ Product specifications may differ by country.
- ◆ Complete product range may not be available in all countries. Contact your local BLACK+DECKER dealers for range availability.

FSMH13151SM

스팀맵

기술 데이터

		FSMH13151SM
전압	V _{AC}	220-240
전력	W	1300
탱크 용량	ml	500
무게	kg	2.8

용도

BLACK+DECKER™ FSMH13151SM 코팅 및 방수 처리된 합판, 코팅 및 방수 처리된 원목, 리놀륨, 비닐, 세라믹 타일, 석재 및 대리석 바닥의 오염물질을 제거하고 청소 할 수 있도록 제작 되었습니다. 본제품은 실내 가정용입니다.

안전 지침



경고! 안전 경고와 지시 사항을 모두 읽으십시오. 아래 나열된 경고와 지시 사항을 준수하지 않으면 감전, 화재 및/또는 심각한 부상을 초래할 수 있습니다.



경고! 주 전원 공급으로 구동되는 제품을 사용할 때는 화재, 감전, 신체 부상 및 중대한 손상의 위험을 줄이기 위해 항상 다음과 같은 기본적인 안전 주의 사항에 따라 사용해야 합니다.

- ◆ 본 사용 설명서에 제품의 용도가 설명되어 있습니다. 본 사용 설명서에서 권장하는 방식 이외의 다른 방식으로 본 제품을 조작하거나 액세서리 또는 부착물을 사용하는 경우 신체 부상의 위험이 있을 수 있습니다.
- ◆ 향후 참고할 수 있도록 본 사용 설명서를 잘 보관해두십시오.

제품 사용

- ◆ 사람, 동물, 가전 제품 또는 전기 콘센트 쪽으로 스팀이 향하지 않도록 하십시오.
- ◆ 비에 노출되지 않도록 하십시오.
- ◆ 본 제품을 물에 담그지 마십시오.
- ◆ 본 제품의 곁을 비우지 마십시오.
- ◆ 사용하지 않을 때는 제품을 전기 콘센트에 연결한 상태로 두지 마십시오.
- ◆ 제품을 소켓에서 분리할 때 절대로 충전기 리드 선을 잡아당기지 마십시오. 제품이 열, 오일 및 날카로운 가장자리에 닿지 않도록 하십시오.
- ◆ 스팀 클리너를 젖은 손으로 다루지 마십시오.
- ◆ 코드로 잡아 당기거나 들고 다니거나, 코드를 손잡이로 사용하거나 날카로운 모서리 주변으로 코드를 잡아당기거나 코드를 가열된 표면에 노출시키지 마십시오.
- ◆ 유성 도료 희석제에서 분비되는 증기, 일부 방충 가공, 가연성 분진 또는 기타 폭발성 또는 독성 증기가 가득한 밀폐된 공간에서 제품을 사용하지 마십시오.

- ◆ 바닥 유형은 바닥제조업체에 문의하여 확인하십시오.
- ◆ 가죽, 왁스 광택제 가구 또는 바닥, 합성 섬유, 벨벳 또는 기타 증기에 약하고 민감한 민감한 재질에서 사용하지 마십시오.



경고! 비처리 목재 또는 비처리 합판 바닥에서 사용하지 마십시오. 왁스로 처리된 표면 또는 일부 왁스가 처리되지 않은 바닥은 열과 증기 작용으로 인해 광택이 벗겨질 수 있습니다. 항상 진행하기 전에 청소할 표면의 고립된 영역을 테스트해 보는 것이 좋습니다. 또한 마루 제조업체의 사용 및 주의 지시 사항을 확인하는 것이 좋습니다.

- ◆ 제석, 방향성, 알코올 또는 세제 제품을 스팀 클리너에 넣지 마십시오. 이로 인해 제품이 손상되거나 사용시 안전하지 않을 수 있습니다.
- ◆ 스팀 기능을 사용하는 동안 가정의 회로 차단기가 작동하는 경우, 즉시 제품 사용을 중단하고 고객 지원 센터에 문의하십시오. (감전 위험에 대해 주의하십시오.)
- ◆ 본 제품은 매우 뜨거운 증기를 내뿜어서 사용 영역을 살균합니다. 이는 스팀 헤드, 클리닝 패드 및 카펫 부착물이 사용 중에 매우 뜨거워진다는 의미입니다.

주의! 스팀맷을 사용하고 스팀맷의 액세서리를 바꿀 때는 적합한 신발을 신고 하십시오. 슬리퍼 또는 발가락 부분이 트인 신발을 신지 마십시오.

- ◆ 뚜껑은 사용 중에 뜨거워질 수 있습니다.
- ◆ 사용 중에 제품에서 증기가 새어나갈 수 있습니다.
- ◆ 이 제품을 사용할 때는 각별히 주의해야 합니다. 사용 중에 뜨거워질 수 있는 부품을 만지지 마십시오.
- ◆ 물 탱크를 분리하기 전에 제품 스위치를 끄고 핸들을 똑바로 세워 두십시오.
- ◆ 스팀이 소형 스팀 클리너의 본체에서 빠져 나오는 것이 보일 경우, 스위치를 끄고 기기를 메인 공급 장치에서 분리하고 열을 식히십시오. 가까운 공인 수리점에 문의하십시오. 제품을 계속해서 사용하지 마십시오.

사용 후

- ◆ 청소한 후에 제품의 플러그를 뽑아서 열을 식히십시오.
- ◆ 사용하지 않을 때에는 본 제품을 습기가 없는 건조한 장소에 보관해야 합니다.
- ◆ 어린이가 보관된 제품을 만지지 못하도록 해야 합니다.

검사 및 수리

- ◆ 유지 보수하거나 수리하기 전에 제품의 플러그를 뽑아서 열을 식히십시오.

- ◆ 사용 전, 제품에 손상되거나 결함 있는 부품이 있는지 점검하십시오. 부품 파손, 스위치 손상 등 정상적 사용에 영향을 미칠 수 있는 제품 이상이 있는지 점검하십시오.
- ◆ 전원 리드 선의 손상 여부를 주기적으로 점검하십시오.
- ◆ 손상되거나 결함 있는 부품이 있는 경우에는 제품을 사용하지 마십시오.
- ◆ 손상되거나 결함 있는 부품은 공인 수리 대리점에 의뢰하여 교체 또는 수리하십시오.
- ◆ 본 사용 설명서에 명시된 내용 이외에는 어떤 부품도 제거하거나 교체하지 마십시오.

다른 사람들의 안전

- ◆ 이 제품은 신체, 지각능력 또는 정신 능력이 낮거나 경험 및 지식이 부족한 사람(어린이 포함)이 사용하도록 설계되지 않았습니다. 어린이가 제품을 가지고 놀게 해서는 안 됩니다. 청소 및 사용자 유지 보수를 할 때 감독 없이 어린이 혼자 해서는 안 됩니다.
- ◆ 어린이가 본 제품을 가지고 놀지 못하도록 항상 주시해야 합니다.

기타 발생 가능한 위험

제품을 사용할 때 동봉된 안전 경고에 포함되어 있지 않은 기타 발생 가능한 위험들이 발생할 수 있습니다. 이러한 위험은 오용, 장시간 사용 등으로 인해 발생할 수 있습니다.

관련된 안전 규정을 준수하고 안전 장치를 사용한다고 해도 어떤 위험들

은 피하지 못할 수도 있습니다. 이러한 위험으로는 다음과 같은 것들이 있습니다.

- ◆ 작동 부품을 만져 발생하는 부상.
- ◆ 뜨거운 부품을 만져 발생하는 부상.
- ◆ 부품 또는 액세서리 변경으로 인한 부상.
- ◆ 장시간에 걸친 제품 사용으로 인한 부상. 어떤 제품이든 장시간에 걸쳐 사용할 때는 반드시 정기적인 휴식을 취하십시오.

전기 안전



경고! 본 제품은 접지해야 합니다. 전원이 전동기 라벨에 기재된 전압과 일치하는지 항상 확인하십시오.

전원 플러그는 콘센트와 형식이 일치해야 합니다. 플러그를 어떤 형태로든 개조하지 마십시오. 개조되지 않은 플러그 및 형식이 일치하는 콘센트를 사용하면 감전 위험이 줄어듭니다.

- ◆ 전원 코드가 손상된 경우 사고가 발생하지 않도록 제조업체 또는 공인 BLACK+DECKER 서비스 센터에서 교체해야 합니다.

연장 케이블 및 Class 1 제품

- ◆ 제품이 접지되어 있고 Class 1 구조이므로 3심 케이블을 사용해야 합니다.

제품에 부착된 라벨

제품에는 제품에 표시된 낱자 코드와 함께 다음과 같은 그림 문자가 있습니다.



주의 뜨거운 증기.
화상 위험.



거꾸로 사용 시 물 떨어짐



모든 측면에서 스팀이
빠져 나옴



어린이를 혼자 두고 제품
걸을 떠나지 마십시오



60°C에서 세탁하고,
표백 또는 섬유 유연제를
사용하지 마십시오

기능

본 제품에는 다음 기능들 중 일부 또는 전체가 포함되어 있습니다.

1. 켜짐/꺼짐 스위치
2. 스마트 셀렉트 다이얼
3. 핸디형 스팀장치 핸들
4. 주입구 뚜껑
5. 핸디형 스팀장치
6. 스팀맷 손잡이
7. 상단 케이블 정돈 걸이
8. 주 핸들
9. 하단 케이블 정돈 걸이
10. 핸디형 스팀장치 탈착 버튼
11. 핸디형 스팀 고정 본체
12. 플로어 클리닝 헤드
- 12a. 스팀 분사 버튼
13. 플로어 클리닝 패드
14. 플로어 클리닝 패드 탈착 탭
15. 벽걸이 브라켓
16. 스팀 호스
- 16a. 호스 탈착 버튼
17. 스팀 노즐
18. 유리창 청소 노즐
(샤워 스크린/유리/거울/뒤편에서 사용 시)
19. 스팀 분사 브러시 본체

- 19a. 스팀 분사 와이어 브러시
(BBQ / 오븐에서 사용 시)
- 19b. 스팀 분사 브러시
(BBQ / 오븐 / 오븐 요리판 / 수도꼭지 /
그라우트에서 사용 시)
- 19c. 스팀 분사 와이드 브러시
(더 큰 작업 표면에서 사용 시)
20. 델타 헤드
- 20a. 델타헤드 패드
21. 스팀 분사 노즐
22. 스팀미트™
23. 스팀미트™ 호스
24. 스팀미트™ 클리닝 패드

조립



경고! 다음 지침을 시도하기 전에, 제품 전원이 꺼졌고 플러그가 분리되었으며 제품이 식었고 물이 들어있지 않은지 확인하십시오.

핸들 장착(그림 A)

- ◆ 제 자리에서 소리가 날 때까지 핸들(8)의 하단 끝 쪽을 스팀맷 본체(11)의 상단 끝 쪽으로 밀어 넣습니다.

핸디형 스팀청소기 장착(그림 B)

- ◆ 스팀맷 본체(11)의 뒤쪽을 잡고 핸디형 스팀 클리너(5)를 스팀맷 본체(11)로 단단히 밀어서 정확하게 인터페이스(11a) 위에 자리하고 제자리에 단단히 고정되었는지 확인합니다.

핸디형 스팀청소기 분리(그림 B)

- ◆ 본체(11)의 탈착 버튼(10)을 누르고 핸디형 스팀 클리너(5)를 인터페이스(11)와 본체(11)에서 들어 올려 분리합니다.

클리닝 패드 부착(그림 C)

교체 클리닝 패드는 BLACK+DECKER 판매점에서 구입할 수 있습니다.

- ◆ 벨크로 '고리' 쪽이 위를 향하도록 한 상태에서 클리닝 패드(13)를 바닥에 놓으십시오.
- ◆ 스팀맷을 클리닝 패드(13)에 놓고 살짝 아래로 누릅니다.

참고: 이 기기에는 스팀 분사 클리닝 헤드(12a)가 제공됩니다. 패드 장착시 위 지침을 참고하여 장착 바랍니다. 어느 경우든, 이러한 지침을 사용하여 클리닝 패드를 장착합니다.

주의! 스팀맷을 일정기간동안 한 장소에 두지 마십시오. 항상 고정 시에는 수직 위치로 하고 핸들(8)을 지지한 상태로 스팀맷을 놓고 사용하지 않을 때는 스팀맷이 꺼졌는지 확인하십시오.

클리닝 패드 분리

주의! 스팀맷의 클리닝 패드를 교체할 때는 항상 적합한 신발을 신으십시오.

슬리퍼 또는 발가락 부분이 트인 신발을 신지 마십시오.

- ◆ 핸들(8)을 똑바로 세우고 스팀맷을 '닫습니다'.
- ◆ 스팀맷이 식을 때까지 기다리십시오(약 5분).
- ◆ 스팀맷을 클리닝 패드에서 들어 올려서 벨크로 체결을 풀니다.

주의! 스팀맷을 일정기간동안 한 장소에 두지 마십시오. 항상 고정 시에는 수직 위치로 하고 핸들(8)을 지지한 상태로 스팀맷을 놓고 사용하지 않을 때는 스팀맷이 꺼졌는지 확인하십시오.

물 탱크 보충 (그림 P)

참고! 깨끗한 수돗물로 물 탱크를 채우십시오(첨가제나 화학제품을 사용하지 마십시오).

참고! 경수 지역의 경우, 비이온화 물을 사용하는 것이 좋습니다.

- ◆ 주입구 뚜껑(4)을 위로 젖혀서 엽니다.
- ◆ 물 탱크에 물을 채우십시오(첨가제나 화학제품을 사용하지 마십시오).

경고! 물을 채울 때는, 본체에서 분리하고 수평으로 유지하십시오.

경고! 물 탱크의 용량은 0.5리터입니다. 탱크에 물을 너무 많이 넣지 마십시오.

- ◆ 주입구 뚜껑(4)을 닫습니다.

참고! 주입구 뚜껑이 확실하게 잠겼는지 확인하십시오.

핸디형 스팀 클리너에 호스 및 액세서리 장착 (그림 G - N)

경고! 매번 사용하기 전에 핸디형 스팀 클리너(5)의 연결 지점과 스팀 호스(16) 사이의 연결 부분을 확인하십시오.

연결 부분이 고장 났거나 손상된 경우 가까운 공인 수리 대리점에 문의하십시오. 본 제품을 사용하지 마십시오.

경고! 호스를 장착하기 전에 기기를 꺼야 합니다.

호스 장착

- ◆ 스팀 호스(16)에 있는 스팀 호스 해제 버튼(16a)을 누릅니다.
- ◆ 스팀 호스(16)를 핸디형 스팀 클리너(5)에 연결하고 제 자리에서 딸깍 소리가 나는지 확인하면서 스팀 호스 해제 버튼(16a)을 놓습니다.

중요! 스팀 호스(16)가 핸디형 스팀 클리너(5)에 단단히 연결되었는지 확인하십시오. 스팀이 이음부에서 빠져 나오는 경우 호스가 잘못 장착된 것입니다. 스위치를 끄고 기기를 식힌 다음 호스를 분리했다가 다시 장착하십시오.

액세서리 장착(그림 H)

- ◆ 스팀 노즐(17)의 돌출된 부분을 액세서리의 홈 안쪽에 맞춥니다.
- ◆ 액세서리를 스팀 노즐(17)에 누르고 액세서리가 제자리에 딱 들어맞을 때까지 시계 반대 방향으로 비틀어 돌립니다.

중요! 자체 호스와 커넥터(23)가 있는 SteaMitt™ (22)를 제외한 모든 액세서리는 사용 시 스팀 호스(16)에 장착되어야 합니다.

호스 및 액세서리 분리

경고! 사용 중에 스팀 호스(16), 스팀 노즐(17) 및 액세서리가 뜨거워질 수 있습니다. 분리하기 전에 기기와 모든 액세서리를 식혀 주십시오.

액세서리 분리

- ◆ 액세서리를 시계 방향으로 비틀어 호스(16)에서 떼어 놓습니다.

호스 분리

- ◆ 스팀 호스(16)에 있는 스팀 호스 해제 버튼(16a)을 눌러서 핸디형 스팀 장치에서 뺍니다.

SteaMitt™

BLACK+DECKERTM SteaMitt™은 타일, 조리대, 주방 표면 및 화장실 표면의 오염을 제거하고 청소할 수 있도록 고안되었습니다. 본 제품은 실내 가정용입니다.

핸디형 스팀 장치에 SteaMitt™ 호스 장착

경고! 매번 사용하기 전에 스팀 노즐과 호스의 연결 부분을 검사하십시오. 밀폐 부분이 없어졌거나 손상된 경우 가까운 공인 수리 대리점에 문의하십시오. **본 제품을 사용하지 마십시오.** 밀봉 부분이 없어졌거나 손상되거나 스팀이 빠져 나오는 경우 SteaMitt™ 및 호스의 연결 부분을 검사한 다음 가까운 공인 수리 대리점에 문의하십시오. **본 제품을 사용하지 마십시오.** SteaMitt™ 호스 또는 부착물 호스에 막힌 부분이 확인하십시오. 발견된 경우 가까운 공인 수리 대리점에 문의하십시오. **본 제품을 사용하지 마십시오.**

SteaMitt™에 클리닝 패드 장착(그림 K)

경고! 스팀 배출구에 막힌 부분이 확인하십시오. 발견된 경우 가까운 공인 수리 대리점에 문의하십시오. **본 제품을 사용하지 마십시오.**

- ◆ 클리닝 패드의 '고리' 벨크로(24a)를 스팀미트™(4)의 '후크' 벨크로 패드(22a)에 장착해서 클리닝패드(24)를 스팀미트™(22)에 장착합니다. 단단히 아래로 누릅니다.

경고! SteaMitt™은 클리닝 패드를 장착하지 않은 상태에서 사용해서는 안됩니다.

- ⚠ **경고!** 항상 그림 M과 같이 보호 장갑 안쪽에 손을 둔 상태에서 SteaMitt™을 사용하십시오.
- ⚠ **경고!** 그림 N과 같이 외부에서 잡아서 SteaMitt™을 사용하려고 하지 마십시오. 화상을 입을 수 있습니다.
- ⚠ **경고!** 그림 O와 같이 너무 좁은 구석에서 SteaMitt™을 사용하지 마십시오.
- ⚠ **경고!** 사용 중에 문제가 발생하는 경우, 그림 P와 같이 신속 분리 탭을 사용해서 손에서 SteaMitt™을 신속하게 놓으십시오.
- ⚠ **경고!** 갑작스러운 온도 변화로 인해 손상이 있을 수 있으므로 창문 등 차가운 유리에서 SteaMitt™을 사용하지 마십시오.
- ⚠ **경고!** 절대로 자신 또는 다른 사람 쪽으로 미트를 가리키거나 향하지 마십시오.

참고: 패드가 너무 젖지 않도록 하려면 SteamMitt을 목재/합판 설정에서 사용해야 합니다.

사용법

중요! 이 기기는 본 설명서의 지침에 따라 사용하고 초극 세사 패드를 부착하고 90초 동안 연속 작동했을 때 세균과 미생물을 99.9% 살균할 것입니다.

전원 켜기/끄기

- ◆ 제품 스위치를 켜려면, ON/OFF 스위치(1)를 누릅니다. 스팀맵을 예열하려면 약 15초가 걸립니다.
- ◆ 제품 스위치를 끄려면, ON/OFF 스위치(1)를 누릅니다.

참고: 항상 스팀 버튼을 누르기 전에 SteaMitt™ 안쪽에 손을 두십시오.

주의! 스팀맵을 일정기간동안 한 장소에 세워두지 마십시오.

항상 고정 시에는 수직 위치로 하고 핸들(8)을 지지한 상태로 스팀맵을 놓고 사용하지 않을 때는 스팀맵이 꺼졌는지 확인하십시오.




주의! 항상 사용 후에는 물통을 비워주세요.

참고! 처음 물을 채웠거나 건조한 상태로 작동한 후에는 스팀이 생성되는 데 최대 45초 걸릴 수 있습니다.

스마트 셀렉트 기술(그림 Q)

본 스팀맵에는 다양한 청소 용도를 보여 주는 스마트 셀렉트 다이얼(2)이 장착되어 있습니다. 이를 사용해서 특정 청소를 위한 정확한 작동 모드를 선택합니다.

스마트 셀렉트를 사용해서, 필요한 설정이 선택될 때까지 스마트 셀렉트 다이얼(2)을 돌려서 다음 용도 중 하나를 선택하십시오.

설정	맵	핸디형
	목재/합판	중기 유량 적음 ●
	타일/비닐	중기 유량 중간 ● ●
	석재/대리석	중기 유량 많음 ● ● ●

스팀맵이 특정 청소 작업에 필요한 정확한 스팀 양을 선택할 것입니다.

참고: 스팀맵을 사용하기 전에 정확한 설정으로 사용하고 있는지 확인하십시오.

스팀 분사(그림 C1)

플로어 헤드(12a)에는 스팀 분사 페달이 장착되어 있어서 없애기 힘든 자국과 얼룩을 제거하는 데 도움이 됩니다.

- ◆ 사용하는 동안 스팀 분사 페달을 눌러서 추가로 세척력을 가합니다.
- ◆ 일반 설정으로 되돌아가려면, 페달을 다시 누릅니다.

최적의 사용법

일반

주의: 절대로 클리닝 패드를 장착하지 않은 상태에서 스팀맵을 사용하지 마십시오.

- ◆ 스팀맵을 사용하기 전에 항상 바닥을 진공 청소하거나 빗자루로 청소하십시오.
- ◆ 제품을 사용하는 가장 쉬운 방법은 핸들을 45도로 기울여서 한 번에 적은 영역을 천천히 청소하는 것입니다.
- ◆ 스팀맵에는 첨가제나 화학물질을 넣지 않은 물만 사용하십시오. 비닐 또는 리놀륨 바닥에서 없애기 힘든 오염을 제거하려면, 스팀맵을 사용하기 전에 중성 세제와 약간의 물로 사전 처리할 수 있습니다.

걸레를 사용한 스팀 청소

- ◆ 핸디형 스팀청소기(5)를 스팀맵 본체(11)에 장착합니다.
- ◆ 벨크로 '고리' 쪽이 위를 향하도록 한 상태에서 클리닝 패드(13)를 바닥에 놓으십시오.
- ◆ 스팀맵을 클리닝 패드(13)에 놓고 살짝 아래로 누릅니다.
- ◆ 스팀맵을 메인 콘센트에 연결합니다.
- ◆ ON/OFF 버튼(1)을 누릅니다. 스팀맵을 예열하려면 약 15초가 걸립니다.

- ◆ 스마트 셀렉트 다이얼(2)을 돌려서 필요한 설정에 놓습니다. 몇 초 후에 스팀 헤드에서 증기가 나오기 시작합니다.

참고! 처음 물을 채웠거나 건조한 상태로 작동한 후에는 스팀이 생성되는 데 최대 45초 걸릴 수 있습니다.

- ◆ 스팀이 클리닝 패드에 들어가려면 몇 초가 걸립니다. 스팀맵은 살균/청소할 표면 위로 쉽게 미끄러집니다.
- ◆ 표면에서 천천히 스팀맵을 끌어 당겨 모든 부분을 철저히 스팀 청소합니다.
- ◆ 스팀맵 사용을 마쳤으면, 스팀맵이 지지되고 있고 꺼졌는지 확인하면서 핸들(8)을 수직 위치로 돌려 놓습니다. 스팀맵이 식을 때까지 기다리십시오(약 5분).

주의! 물 탱크의 수위를 모니터링하는 것이 중요합니다. 물 탱크를 보충하고 살균/청소를 계속하려면 핸들이 지지되어 있고 스팀맵이 'OFF' 상태인지 확인하면서 스팀맵을 세워두십시오. 전기 벽 콘센트에서 기기의 플러그를 뽑고, 물 탱크를 다시 채웁니다.

주의! 스팀맵을 일정기간동안 한 장소에 두지 마십시오. 항상 고정 시에는 수직 위치로 하고 핸들(8)을 지지한 상태로 스팀맵을 놓고 사용하지 않을 때는 스팀맵이 꺼졌는지 확인하십시오.

사용 후

- ◆ 스마트 셀렉트 다이얼(2) OFF 위치로 바꿉니다.
- ◆ 스팀맵이 식을 때까지 기다리십시오.
- ◆ 전기 벽 콘센트에서 스팀맵의 플러그를 뽑으십시오.
- ◆ 물 탱크를 비우십시오.
- ◆ 클리닝 패드(13)를 분리하여 다음 사용을 위해 닦아 놓으십시오(클리닝 패드에 인쇄되어 있는 세척 관리 지침 사항을 준수하십시오).
- ◆ 케이블 정돈 길이(7 및 9)에 공급 케이블을 정리합니다.
- ◆ 케이블 정리 시 당기거나 팽팽하게 감지 마십시오.
- ◆ 핸드 그립(6)에 장착되어 있는 벽걸이 브라켓(15)이 있어 스팀맵을 벽에 있는 적절한 고리에 걸 수 있습니다. 항상 벽걸이가 스팀맵의 무게를 안전하게 지탱할 수 있는지 확인하십시오. 사용중이나 보관할때 케이블을 강하게 당기거나 팽팽하게 당겨 사용하지 마십시오.

핸디형 스팀 클리닝

경고! 사용하는 동안 기기를 수평으로 유지하십시오.

- ◆ 필요한 액세서리를 부착합니다.
- ◆ 핸디형 스팀 클리너를 메인 콘센트에 연결합니다.
- ◆ ON/OFF 버튼(1)을 누릅니다. 스팀맵을 예열하려면 약 15초가 걸립니다.
- ◆ 스마트 셀렉트 다이얼(2)을 돌려서 필요한 설정에 놓습니다. 몇 초 후에 스팀 헤드에서 증기가 나오기 시작합니다.

참고! 처음 물을 채웠거나 건조한 상태로 작동한 후에는 스팀이 생성되는 데 최대 45초 걸릴 수 있습니다.

- ◆ 핸디형 스팀 클리너의 사용을 마쳤으면, 스마트 셀렉트 다이얼(2)을 OFF 위치로 놓으십시오. ON/OFF 버튼(1)을 돌려서 기기를 끄고 메인 공급 장치에서의 연결을 끊습니다. 보관하기 전에 기기가 식을 때까지 기다리십시오(약 5분).

액세서리

제품의 성능은 사용한 액세서리에 따라 결정됩니다. BLACK+DECKER 액세서리는 높은 품질 기준을 만족하도록 제조되었으며, 제품의 성능을 향상시키도록 설계되었습니다. 이러한 액세서리를 사용함으로써 제품의 기능을 최대한 활용할 수 있습니다.

문제 해결

제품이 제대로 작동하지 않는 것 같은 경우, 아래의 지침을 따르십시오. 문제가 해결되지 않는 경우, 가까운 BLACK+DECKER 수리 대리점에 문의하십시오.

문제	조치	가능한 해결책
스팀맵이 켜지지 않는다	1.	벽 콘센트에 기기의 플러그가 꽂혀 있는지 확인하십시오.
	2.	ON/OFF 스위치(1)를 사용해서 기기의 전원이 켜지는지 확인하십시오.
	3.	플러그의 퓨즈를 확인하십시오.
스팀맵에서 스팀이 나오지 않는다	4.	스팀맵은 핸디형 스팀 클리너(5)가 본체(11)에 정확하게 장착되어 있거나 스팀 호스가 장착되어 있거나 스마트 셀렉트가 ON에 있을 경우에만 스팀이 생성됩니다.
	5.	물 탱크가 가득 차 있는지 확인하십시오. 참고: 처음 물을 채웠거나 건조한 상태로 작동한 후에는 스팀이 생성되는 데 최대 45초 걸릴 수 있습니다.
	6.	조치 1, 2 및 3을 순서대로 확인하십시오.
사용 중에 스팀맵의 스팀 생성이 멈춘다	7.	조치 4, 5 및 3을 순서대로 확인하십시오.
사용 중에 스팀이 너무 많이 나온다	8.	스마트 셀렉트 다이얼(2)을 시계 반대 방향으로 돌려서 스팀 생성 양을 줄이십시오.
사용 중에 스팀이 너무 적게 나온다	9.	스마트 셀렉트 다이얼(2)을 시계 방향으로 돌려서 스팀 생성 양을 늘리십시오.
핸디형 스팀 클리너에서 스팀이 생성되지 않는다	10.	스마트 셀렉트 다이얼(2)이 켜짐(ON) 위치에 있는지 확인하십시오.
	11.	조치 5, 1, 2 및 3을 순서대로 확인하십시오.
사용 중에 핸디형 스팀 클리너의 스팀이 너무 적게 나온다	12.	스마트 셀렉트 다이얼(2)을 시계 방향으로 돌려서 스팀 생성 양을 늘리십시오.
	13.	조치 5를 확인하십시오.

문제	조치	가능한 해결책
사용 중에 핸디형 스팀 클리너의 스팀이 너무 많이 나온다	14.	스마트 셀렉트 다이얼(2)을 시계 반대 방향으로 돌려서 스팀 생성 양을 줄이십시오.
기지에서 액세서리가 계속 떨어진다	15.	모든 부품 및 액세서리의 정확한 장착 지침을 위해 조립 방법을 참조하십시오.
기기의 예상치 못한 곳에서 스팀이 빠져 나온다	16.	모든 부품 및 액세서리의 정확한 장착 지침을 위해 조립 방법을 참조하십시오.
추가 정보/액세서리를 어디에서 얻을 수 있습니까?	17.	www.blackanddecker.co.kr

유지보수 및 청소

BLACK+DECKER 유선 제품은 최소한의 유지 보수로 장기간에 걸쳐 작업이 가능하도록 설계되어 있습니다. 만족스러운 동작을 계속 유지하려면 적절한 제품 관리와 정기적인 청소가 필요합니다.

경고! 유선 제품의 유지 보수 또는 청소를 수행하기 전에 전원을 끄고 제품의 플러그를 뽑으십시오.


- ◆ 부드러운 젖은 헝겊으로 제품을 닦으십시오.
- ◆ 없애기 힘든 자국이 있는 경우, 따뜻한 비누와 물을 사용하여 헝겊을 축일 수 있습니다.

클리닝 패드 관리

세척 관리 지침 – 섬유 유연제 없이 사용 – 다시 사용하기 전에 충분히 말리십시오.

주의! 클리닝 패드 라벨에 인쇄되어 있는 클리닝 지침 사항을 따르십시오.

환경 보호

 분리 수거. 이 기호가 표시된 제품과 배터리를 일반 가정용 쓰레기와 함께 처리하면 안 됩니다.

제품과 배터리에는 재용되거나 재활용되고 고철 자원에 대한 수요를 줄일 수 있는 자재가 포함되어 있습니다. 전기 제품과 배터리는 지역 규정에 따라 재활용하십시오. 자세한 내용은 www.2helpU.com 에서 찾아 볼 수 있습니다.

서비스 정보

블랙앤데커 제품은 공식 인증된 서비스센터를 통해서 보증 서비스를 받으실 수 있습니다. 자세한 공식 서비스센터 안내 및 보증 서비스 안내는 블랙앤데커 홈페이지나 고객지원센터 1577-0933에서 확인하실 수 있습니다.

참고

- ◆ BLACK+DECKER는 제품을 지속적으로 개선시키기 때문에 사전 통지 없이 제품 사양이 변경될 수 있습니다.
- ◆ 기본 장비 및 액세서리 구성은 각 국가에 따라 다를 수 있습니다.
- ◆ 제품 사양은 국가에 따라 다를 수 있습니다.
- ◆ 국가에 따라 판매하지 않는 제품도 있을 수 있습니다. 제품 판매 여부는 해당 지역에 있는 BLACK+DECKER 판매점으로 문의하십시오.

