









Intended use

Your BLACK+DECKER steam mop has been designed for sanitising and cleaning sealed hardwood, sealed laminate, linoleum, vinyl, ceramic tile, stone and marble floors and for refreshing carpets. This appliance is intended for indoor household use only.



Warning! Read all of the 'Safety, Maintenance, Service' manual carefully before operating this appliance.

Read all of this manual carefully before operating the appliance.

Features

This appliance includes some or all of the following features.

1. ON/Off switch
2. Lock off button
3. Trigger switch
4. Steam nozzle
5. Hand held steam cleaner
6. Autoselect™ button
7. Filler cap
8. Water tank
9. Steam mop body
10. Handle
11. Steam head
12. Steam head cleaning pad
14. Carpet glider (Not included in FSMH1621S)
15. Bottom cable tidy hook
16. Top cable tidy hook
17. Cable management clip

Assembly

Warning! Before attempting any of the following operations, make sure that the appliance is switched off and unplugged and that the appliance is cold and does not contain any water.

Attaching the handle (Fig. A)

- ◆ Slide the bottom end of the handle (10) into the top end of the steam mop body (9) until it clicks into place. The arrow on the handle (10) should be aligned with the top of the steam mop body (9).

Attaching the steam head (Fig. B)

- ◆ Slide the bottom end of the steam mop body (9) onto the steam head (11) until it clicks into place.
- ◆ The steam head can be removed from the Steam mop body by pressing the steam head release button (19) and pulling the steam mop body (9) off the steam head (11).

Attaching the hand held steam cleaner (Fig. C)

- ◆ Holding the back of the steam mop body (9) Push the hand held steam cleaner (5) firmly into the steam mop body (9) until it clicks into place.

Caution! Always ensure the handle command lights up to confirm the unit is docked.

Warning! Inspect that the seal (26 Fig. J) on the steam nozzle (4) before fitting the hand held steam mop to the steam mop body. If the seal is missing or damaged then please contact your nearest authorised repair agent. Do not use the appliance.

Removing the hand held steam cleaner (Fig. C)

- ◆ Push the release button (20) down and pull the hand held steam cleaner (5) away from the steam mop body

Attaching a cleaning pad (Fig. D)

Replacement cleaning pads are available from your BLACK+DECKER dealer:

Steam head cleaning pad (12) - cat. no. FSMP20-XJ).

- ◆ Place a cleaning pad (12) on the floor with the 'hook & loop' side facing up.
- ◆ Lightly press the steam mop down onto the cleaning pad (12).

Caution! Always place your steam mop with the handle (10) in the upright position when stationary and make sure the steam mop is turned off when not in use.

Removing a cleaning pad (Fig. E)

Caution! Always wear suitable shoes when changing the cleaning pad on your steam mop. Do not wear slippers or open toed footwear.

- ◆ Return the handle (10) to the upright position and turn the steam mop 'OFF'.
- ◆ Wait until the steam mop cools down. (approximately five minutes)
- ◆ Place the front of your shoe onto the cleaning pad removal tab (21) and press down firmly.
- ◆ Lift the steam mop up off the cleaning pad.

Caution! Always place your steam mop with the handle (10) in the upright position when stationary and make sure the steam mop is turned off when not in use.

Filling the water tank (Fig. F)

This Steam cleaner incorporates an anti-calc system to help prolong the life of the system.

Note: Fill the water tank with clean tap water.

Note: In areas of very hard water, the use of de-ionised water is recommended.

- ◆ Open the filler cap (7) by flipping it down.
- ◆ Fill the water tank (8) with water.

Warning! Your water tank has a 0.36 litre capacity.

- ◆ Re-fit the filler cap (7).

Note: Ensure the filler cap is firmly secured.

Note: Do not use chemical cleaners with your steam mop..

Attaching the carpet glider (Fig. G) (For use on carpets only) (Not included in FSMH1621S)

- ◆ Place carpet glider on the floor.
- ◆ Attach a cleaning pad to the unit.
- ◆ Lightly press the steam mop down onto the carpet glider (14) until it clicks into place.

Caution! Always place your steam mop with the handle (10) in the upright position when stationary and make sure the steam mop is turned off when not in use.

Removing the carpet glider (Fig. G)

Caution! Always wear suitable shoes when changing the carpet glider on your steam mop. Do not wear slippers or open toed footwear.

- ◆ Return the handle (10) to the upright position and turn the steam mop 'OFF'.
- ◆ Wait until the steam mop cools down. (approximately five minutes)
- ◆ Place the front of your shoe onto the carpet glider removal tab (22) and press down firmly.
- ◆ Lift the steam mop up off the carpet glider (14).

Caution! Always place your steam mop with the handle (10) in the upright position when stationary and make sure the steam mop is turned off when not in use.

Fitting a scent pack (Fig. I & J)

Warning! Return the handle (10) to the upright position and turn the steam mop 'OFF'. Wait until the steam mop cools down. (approximately five minutes).

- ◆ Slide the door release button (26), the door will open.
- ◆ Place the scent pack into the cavity (27).
- ◆ Close the door (28) by pushing it firmly down.

Attaching the hose and accessories to the Hand held steam cleaner (Fig. K & L)

Warning! Inspect the seal (26) on the steam nozzle (4) and hose (27) before each use. If the seal is missing or damaged then please contact your nearest authorised repair agent. Do not use the appliance.

Attaching the hose (Fig. K)

- ◆ Press in the clips (28) on either side of the hose (27).
- ◆ Press the hose (27) onto the steam nozzle (4) and release the clips (28).

Important! Ensure that the hose (27) is securely fastened before using the hand held steam cleaner. If steam escapes from the joint then the hose is not correctly fit, allow the unit to cool then remove and re-fit the hose.

Attaching the variable steam jet nozzle (Fig. L)

- ◆ Press in the clips (30) on either side of the variable steam jet nozzle (31).
- ◆ Press the variable steam jet nozzle onto the steam nozzle (4) or the hose (27) and release the clips (30).

Important! Ensure that the variable steam jet nozzle (31) is securely fastened before using the hand held steam cleaner. If steam escapes from the joint then the variable steam jet nozzle is not correctly fit, allow the unit to cool then remove and re-fit the variable steam jet nozzle.

Attaching other accessories (Fig. J)

- ◆ Align the lugs on the hose with the recesses on the accessory.
- ◆ Press the accessory (29) onto the hose (27) and twist anti-clockwise until the accessory clicks into place.

Note! The variable steam jet nozzle may be used without the hose by fitting them directly to steam nozzle. All other accessories must be connected to the hose for use.

Removing the hose and accessories (Fig. K & L)

Warning! The Steam nozzle, variable steam jet nozzle, hose and accessories become hot during use. Allow the unit and all accessories to cool before removing any accessories.

Removing an accessory (Fig. K)

- ◆ Twist the accessory (29) clockwise then pull away from the hose (27).

Removing the hose (Fig. K)

- ◆ Press in the clips (29) on either side of the hose (27) and pull away from the steam nozzle (4).

Removing the variable steam jet nozzle (Fig. L)

- ◆ Press in the clips (30) on either side of the variable steam jet nozzle (31) and pull away from the steam nozzle (4).

Use

Important! This unit will kill 99.9% of bacteria & germs when used in accordance with this manual and with the micro fibre pad fitted and a continuous run time of 90 seconds.

Switching on and off (Steam mop)

- ◆ To switch the appliance on, press the ON/OFF button (1). It takes approximately 15 seconds for the steam mop to heat up.

Note: When the steam mop is first turned on the water reservoir will glow red. Once the steam mop is ready to use the water reservoir will glow blue.

- ◆ To switch the appliance off, press the ON/OFF button (1).

Caution! Never leave the steam mop in one spot on any surface for any period of time. Always place the steam mop with the handle (10) in the upright position when stationary and make sure the steam mop is turned off when not in use.

Caution! Always empty the steam mop after use.

Note: When first filled or after running dry it can take up to 45 seconds for steam to be produced.

Autoselect™ Technology (Fig. I)

This steam mop is fitted with an Autoselect™ button (6) which shows various cleaning applications. They are used to select the correct operating mode for your particular cleaning operation.

Using Autoselect™, choose from one of the following applications by pressing the autoselect button (6) until the required setting is selected:

	Wood/Laminate
	Stone/Marble
	Tiles/Vinyl

The steam mop will select the correct volume of steam required for your particular cleaning operation.

Note: Always check you are using the correct setting before using your steam mop. For convenience the steam mop will remember the last setting you chose.

Steam burst (Fig. I)

The steam mop is equipped with a steam burst button to aid in the removal of stubborn marks and stains.

- ◆ During use, press the steam burst button (25) to apply extra cleaning power.

Note: The steam burst will last for 10 seconds then the steam mop will return to the chosen setting.

Switching on and off (Hand held steam cleaner) (Fig. M)

- ◆ To switch the appliance on, press the ON/OFF button (1). It takes approximately 15 seconds for the hand held steam cleaner to heat up.

Note: When the hand held steam cleaner is first turned on the water reservoir will glow red. Once the hand held steam cleaner is ready to use the water reservoir will glow blue.

- ◆ Lift the lock off switch (2) and pull the trigger switch (3). After a few seconds steam will be produced.
- ◆ To switch the appliance off, release the trigger switch (3) then press the ON/OFF button (1).

Caution! Always empty the hand held steam cleaner after use.

Caution! Steam may continue to be produced for a short time after the trigger switch (3) is released, this is normal. Switch off and allow the unit to cool before removing any accessories.

Hints for optimum use

General

Caution! Never use the steam mop without first attaching a cleaning pad.

- ◆ During steam mop use you can use the cable management clip (17) to keep your cable out of the way of the work area..
- ◆ Always vacuum or sweep the floor before using the steam mop.
- ◆ The easiest way to use the machine is to tilt the handle to a 45° angle and clean slowly, covering a small area at a time.
- ◆ Do not use chemical cleaners with your steam mop. To remove stubborn stains from vinyl or linoleum floors, you can use the steam burst button to apply extra steam to the area or pre-treat with a mild detergent and some water before using the steam mop.

Steam cleaning with the mop

- ◆ Fit hand held steam cleaner (5) to the steam mop body (9).
- ◆ Place a cleaning pad (12) on the floor with the 'hook & loop' side facing up.
- ◆ Lightly press the steam mop down onto the cleaning pad (12).
- ◆ Connect the steam mop to the mains.
- ◆ Press the ON/OFF button (1). It takes approximately 15 seconds for the steam mop to heat up.
- ◆ Press the Autoselect™ button (6) till the required setting is reached.
- ◆ Pulling the handle (10) back will activate the steam pump. After a few seconds steam will start to come out of the steam head.

Note: When first filled or after running dry it can take up to 45 seconds for steam to be produced.

- ◆ It takes a few seconds for steam to enter the cleaning pad. The steam mop will now glide easily over the surface to be sanitised/cleaned.
- ◆ Push and pull the steam mop slowly across the floor to thoroughly steam clean each section.

Note: During use you may turn off the steam pump by returning the handle to the upright position, this convenient feature will allow you to leave the steam mop for a short time so that you may move items of furniture, then continue cleaning without the need to switch the appliance off.

- ◆ When you have finished using the steam mop, return the handle (10) to the upright position and turn it 'OFF' and wait until the steam mop cools down. (approximately five minutes)

Caution! It is important to monitor the water level in the water tank. To refill the water tank and continue to sanitise/clean, return the handle (10) to the upright position and turn the steam mop 'OFF'. Unplug the unit from the electrical wall outlet, refill the water tank (8).

Caution! Never leave the steam mop in one spot on any surface for any period of time. Always place the steam mop with the handle (10) in the upright position when stationary and make sure the steam mop is turned off when not in use.

Carpet refreshing

- ◆ Place a cleaning pad (12) on the floor with the 'hook & loop' side facing up.
- ◆ Lightly press the steam mop down onto the cleaning pad (12).
- ◆ Place the carpet glider (14) on the floor.
- ◆ Lightly press the steam mop down onto the carpet glider (14) until it clicks into place.
- ◆ Connect the steam mop to the mains.
- ◆ Press the ON/OFF button (1). It takes approximately 15 seconds for the steam mop to heat up.
- ◆ Press the Autoselect™ button (6) to the Wood/Laminate setting.
- ◆ Pulling the handle (10) back will activate the steam pump. After a few seconds steam will start to come out of the steam head.

Note: When first filled or after running dry it can take up to 45 seconds for steam to be produced.

- ◆ Push and pull the steam mop slowly across the carpet to thoroughly refresh each section.

Note: During use you may turn off the steam pump by returning the handle to the upright position, this convenient feature will allow you to leave the steam mop for a short time so that you may move items of furniture, then continue cleaning without the need to switch the appliance off.

- ◆ When you have finished using the steam mop, return the handle (10) to the upright position and turn it 'OFF' and wait until the steam mop cools down. (approximately five minutes)

Caution! If steam is observed escaping from the joint between the hand held steam cleaner and the steam mop body, switch off and disconnect the unit from the mains supply. Allow to cool. Remove the hand held steam cleaner from the steam mop body. Inspect the seal (26) on the steam nozzle (4) and hose (27) (fig. K). If the seal is missing or damaged then please contact your nearest authorised repair agent. Do not use the appliance. If the seal is in good condition re-fit the hand held steam cleaner to the steam mop body ensuring that it is seated firmly in place.

Caution! It is important to monitor the water level in the water tank. To refill the water tank and continue to sanitise/clean, return the handle (10) to the upright position and turn the steam mop 'OFF'. Unplug the unit from the electrical wall outlet, refill the water tank (8).

Caution! Never leave the steam mop in one spot on any surface for any period of time. Always place the steam mop with the handle (10) in the upright position when stationary and make sure the steam mop is turned off when not in use.

After use (Fig. N & O)

- ◆ Return the handle (10) to the upright position and turn the steam mop 'OFF',
- ◆ Wait until the steam mop cools down. (approximately five minutes)
- ◆ Unplug the steam mop from the electrical wall outlet.
- ◆ Empty the water tank (8).
- ◆ Remove the cleaning pad (12) and wash it ready for next use. (Take care to follow the wash care instructions printed on the cleaning pad).
- ◆ Wrap the supply cable around the cable tidy hooks (15 & 16).

Note: The top cable tidy hook (16) rotates to easily release the cable ready for next use.

- ◆ Clip the supply cable onto itself using the cable tidy clip (32) close to the plug.

Note: With the handle (10) in the upright position, the cable neatly wrapped around the cable tidy hooks (15 & 16) and secured with the cable tidy clip (32) your steam mop will stand on its own for storage. Alternatively there is a hanging bracket (33) built into the hand grip (34) which will allow your steam mop to be hung from a suitable hook on the wall. Always ensure that your wall hook is capable of supporting the weight of the steam mop safely.

Hand held steam cleaning

- ◆ Attach the required accessory.
- ◆ Connect the hand held steam cleaner to the mains.
- ◆ Press the ON/OFF button (1). It takes approximately 15 seconds for the hand held steam cleaner to heat up.
- ◆ Lift the lock off (2) and pull the trigger switch (3) to activate the steam pump. After a few seconds steam will start to come out of the accessory.

Note: When first filled or after running dry it can take up to 45 seconds for steam to be produced.

Note: During use you may turn off the steam pump by releasing the trigger switch, this convenient feature will allow you to place the hand held steam cleaner down for a short time so that you may move items of furniture, then continue cleaning without the need to switch the appliance off.

- ◆ When you have finished using the hand held steam cleaner, release the trigger switch (3), turn it 'OFF' and disconnect from the mains supply. Wait until the steam mop cools down before storing. (approximately five minutes)

Caution! It is important to monitor the water level in the water tank. To refill the water tank and continue to sanitise/clean, turn the hand held steam cleaner 'OFF'. Unplug the unit from the electrical wall outlet, refill the water tank (8).

Caution! Steam may continue to be produced for a short time after the trigger switch (3) is released, this is normal. Switch off and allow the unit to cool before removing any accessories.

Accessories

The performance of your appliance depends on the accessory used. BLACK+DECKER accessories are engineered to high quality standards and designed to enhance the performance of your appliance. By using these accessories you will get the very best from your appliance.

Technical data

		FSMH1621S (Type 1)
Voltage	V _{ac}	220
Power	W	1600
Tank capacity	ml	350
Weight	kg	3.6

Troubleshooting

If your appliance seems not to operate properly, follow the instructions below. If this does not solve the problem, please contact your local BLACK+DECKER repair agent.

Problem	Step	Possible solutions
The steam mop is not turning on.	1	Check the unit is plugged in at the wall socket.
	2	Check the unit is switched on using the on/off switch (1).
	3	Check the fuse in the plug.

Problem	Step	Possible solutions
The digital controls do not light up.	4	Check that the handle (10) of the steam mop is pushed firmly into the steam mop body (9). Check that the arrow on the handle is flush with the top of the steam mop body (9).
	5	Check that the hand held steam cleaner (5) is firmly docked into the steam mop body (9).
	6	Check steps 1, then 2, then 3.
The steam mop is not producing steam.	7	The steam mop will only produce steam once the handle is pulled back from the upright position.
	8	Check that the water tank (8) is full. NOTE: When first filled or after running dry it can take up to 45 seconds for steam to be produced.
	9	Check that the Steam head (11) is firmly docked into the steam mop body (9).
	10	Check steps 5, then 1, then 2, then 3.
The digital controls go out during use.	11	Check steps 4, then 5, then 1, then 2, then 3
The steam mop stops producing steam during use.	12	Check steps 7, then 8, then 9, then 5, then 3.
The steam mop is producing too much steam during use.	13	The steam mop has 3 settings. Press the autoselect button (6) to reduce the amount of steam being produced.
	14	Check that the steam burst button (25) has not been pressed.
The steam mop is producing too little steam during use.	15	The steam mop has 3 settings. Press the autoselect button (6) to increase the amount of steam being produced.
	16	Press the steam burst button (25) to temporarily increase the amount of steam.
No steam is being produced from the hand held steam cleaner when the trigger is pulled.	17	The hand held steam cleaner has a lock off feature. Lift the lock off switch (2) and pull the trigger switch (3). After a few seconds steam will be produced.
	18	Check steps 8, then 1, then 2, then 3.
The hand held steam cleaner is producing too little steam during use.	19	The hand held steam cleaner will begin to produce steam after 15 seconds and will reach maximum steam flow after 45 seconds.
The hand held steam cleaner will not come out from the steam mop body.	20	Firmly press the hand held steam cleaner release button (20) down, then pull the hand held steam (5) cleaner from the steam mop body (9).

Problem	Step	Possible solutions
The accessories keep falling off the unit.	21	Refer to the assembly chapter of the manual for correct fitting instructions of all parts and accessories.
Steam is escaping from unexpected areas of the unit.	22	Refer to the assembly chapter of the manual for correct fitting instructions of all parts and accessories.

Protecting the environment



Separate collection. This product must not be disposed of with normal household waste.

Should you find one day that your Black & Decker product needs replacement, or if it is of no further use to you, do not dispose of it with household waste. Make this product available for separate collection.



Separate collection of used products and packaging allows materials to be recycled and used again.

Re-use of recycled materials helps prevent environmental pollution and reduces the demand for raw materials.

Local regulations may provide for separate collection of electrical products from the household, at municipal waste sites or by the retailer when you purchase a new product.

Service Information

Black & Decker offers a full network of company-owned and authorized service locations throughout Asia. All Black & Decker Service Centers are staffed with trained personnel to provide customers with efficient and reliable power tool service. Whether you need technical advice, repair, or genuine factory replacement parts, contact the Black & Decker location nearest to you.

Notes

- ◆ Black & Decker's policy is one of continuous improvement to our products and, as such, we reserve the right to change product specifications without prior notice.
- ◆ Standard equipment and accessories may vary by country.
- ◆ Product specifications may differ by country.
- ◆ Complete product range may not be available in all countries.
- ◆ Contact your local Black & Decker dealers for range availability.

용도

BLACK+DECKER 스팀맷은 포장 건목, 포장 합판, 리놀륨, 비닐, 세라믹 타일, 석재 및 대리석 바닥의 오염 물질을 제거하고 청소할 수 있도록 제작되었습니다. 본 제품은 실내 가정용입니다.



경고! 본 제품을 작동하기 전에 ‘안전, 유지보수, 정비’ 설명서를 모두 주의 깊게 읽고 숙지해주시시오.

제품을 사용하기 전에 본 사용 설명서 전체 내용을 잘 읽고 숙지해주시시오.

기능

본 제품에는 다음 기능들 중 일부 또는 모두가 포함되어 있습니다.

1. 켜짐 / 꺼짐 스위치
2. 잠금 해제 버튼
3. 방아쇠 스위치
4. 스팀 노즐
5. 핸디형 스팀청소기
6. 오토셀렉트™ 버튼
7. 주입구 뚜껑
8. 물 탱크
9. 스팀맷 본체
10. 핸들
11. 스팀 헤드
12. 스팀 헤드 클리닝 패드
14. 카펫 글라이더 (FSMH1621S 에 포함되어 있지 않음, 별매품)
15. 하단 케이블 정돈 걸이
16. 상단 케이블 정돈 걸이
17. 케이블 관리 클립

조립

경고! 다음 조작 중 하나를 시도하기 전에, 제품 전원이 꺼졌고 플러그를 뽑았는지, 그리고 제품의 열이 식었으며 물이 들어 있지 않은지 확인하십시오.

핸들 장착 (그림 A)

- ◆ 제 자리에서 소리가 날 때까지 핸들 (10) 의 하단 끝 쪽을 스팀맷 본체 (9) 의 상단 끝 쪽으로 밀어 넣습니다. 핸들 (10) 의 화살표는 스팀맷 본체 (9) 의 상단에 맞춰 조정해야 합니다.

스팀 헤드 장착 (그림 B)

- ◆ 제 자리에 딸깍 소리가 날 때까지 스팀맷 본체 (9) 의 하단 끝 쪽을 스팀 헤드 (11) 로 밀니다.
- ◆ 스팀 헤드는 스팀 헤드 분리 버튼 (19) 을 누르고 스팀맷 본체 (9) 를 스팀 헤드 (11) 에서 당겨 빼내서 스팀맷 본체에서 분리할 수 있습니다.

핸디형 스팀 청소기 장착 (그림 C)

- ◆ 제 자리에 딸깍 소리가 날 때까지 스팀맷 본체 (9) 의 뒤쪽을 잡고 핸디형 스팀 청소기 (5) 를 스팀맷 본체 (9) 안으로 누릅니다.

주의! 항상 핸들의 핸디형 스팀청소기가 제대로 장착되었는지 확인하십시오.

경고! 스팀맷 본체에 소형 스팀맷을 장착하기 전에 스팀 노즐 (4) 의 고무패킹 부분 (26 그림 K) 을 검사하십시오. 밀폐 부분이 없어졌거나 손상된 경우 가까운 공인 수리 대리점에 문의하십시오. 본 제품을 사용하지 마십시오.

소형 스팀 클리너 분리 (그림 C)

- ◆ 분리 버튼 (20) 을 아래로 밀고 핸디형 스팀 청소기 (5) 를 당겨 스팀맷 본체에서 분리합니다.

클리닝 패드 부착 (그림 D)

교체 클리닝 패드는 BLACK+DECKER 판매점에서 구입할 수 있습니다.

스팀 헤드 클리닝 패드 (12) - 카탈로그 번호 FSMP20-KR).

- ◆ ‘고리’ 쪽이 위를 향하도록 한 상태에서 클리닝 패드 (12) 를 바닥에 놓으십시오.
- ◆ 스팀맷을 클리닝 패드 (12) 에 놓고 살짝 아래로 누릅니다.

주의! 항상 고정 시에는 수직 위치로 한 상태에서 스팀맷을 핸들 (10) 과 함께 놓고 사용하지 않을 때는 스팀맷이 꺼졌는지 확인하십시오.

클리닝 패드 제거 (그림 E)

주의! 스팀맷의 클리닝 패드를 교체할 때는 항상 적합한 신발을 신으십시오. 슬리퍼 또는 발가락 부분이 트인 신발을 신지 마십시오.

- ◆ 핸들 (10) 을 똑바로 세우고 스팀맷을 끕니다.
- ◆ 스팀맷이 식을 때까지 기다리십시오 (약 5 분).
- ◆ 클리닝 패드 제거 탭 (21) 에 신발 앞쪽을 놓고 단단히 아래로 누릅니다.
- ◆ 스팀맷을 위로 올려 클리닝 패드를 제거합니다.

주의! 항상 고정 시에는 수직 위치로 한 상태에서 스팀

컵을 핸들 (10) 과 함께 놓고 사용하지 않을 때는 스팀
덮이 꺼졌는지 확인하십시오 .

물 탱크 보충 (그림 F)

이 스팀 클리너에는 반 석회 시스템이 포함되어 있어 시
스템 수명을 연장시킬 수 있습니다 .

참고 : 물 탱크는 깨끗한 수돗물로 채우십시오 .

참고 : 강한 경우 지역의 경우 , 비이온화 물을 사용하는
것이 좋습니다 .

◆ 주입구 뚜껑 (7) 을 아래로 젖혀서 엽니다 .

◆ 물 탱크 (8) 에 물로 채우십시오 .

경고 ! 물 탱크의 용량은 0.36 리터입니다 .

◆ 주입구 뚜껑 (7) 을 다시 끼우십시오 .

참고 : 주입구 뚜껑이 확실히 잠겼는지 확인하십시오 .

참고 : 스팀덮에 화학제품 클리너를 사용하지 마십시오 .

카펫 글라이더 장착 (그림 G) (카펫에서 사용하 는 경우만 해당) (FSMH1621S 에 포함되어 있 지 않음)

◆ 카펫 글라이더를 바닥에 놓습니다 .

◆ 클리닝 패드를 기기에 부착합니다 .

◆ 제 자리에 딱딱하고 소리가 날 때까지 스팀덮을 카펫
글라이더 (14) 에 놓고 살짝 누릅니다 .

주의 ! 항상 고정 시에는 수직 위치로 한 상태에서 스팀
덮을 핸들 (10) 과 함께 놓고 사용하지 않을 때는 스팀
덮이 꺼졌는지 확인하십시오 .

카펫 글라이더 분리 (그림 G)

주의 ! 스팀덮의 카펫 글라이더를 교체할 때는 항상 적
합한 신발을 신으십시오 . 슬리퍼 또는 발가락 부분이
트인 신발을 신지 마십시오 .

◆ 핸들 (10) 을 똑바로 세우고 스팀덮을 끕니다 .

◆ 스팀덮이 식을 때까지 기다리십시오 . (약 5 분)

◆ 카펫 글라이더 제거 탭 (22) 에 신발 앞쪽을 놓고 단
단히 아래로 누릅니다 .

◆ 스팀덮을 위로 올려 카펫 글라이더 (14) 를 분리합니
다 .

주의 ! 항상 고정 시에는 수직 위치로 한 상태에서 스팀
덮을 핸들 (10) 과 함께 놓고 사용하지 않을 때는 스팀
덮이 꺼졌는지 확인하십시오 .

방향제 장착 (그림 I 및 J)

경고 ! 핸들 (10) 을 똑바로 세우고 스팀덮을 끕니다 . 스
팀덮이 식을 때까지 기다리십시오 . (약 5 분) .

◆ 도어 탈착 버튼 (35) 을 밀면 , 도어가 열립니다 .

◆ 방향제를 캐비티 (36) 안에 넣으십시오 .

◆ 단단히 내려 눌러서 도어 (37) 를 닫습니다 .

소형 스팀 클리너에 호스 및 액세서리 부착 (그림 K 및 L)

경고 ! 매번 사용하기 전에 스팀 노즐 (4) 과 호스 (27)
의 고무패킹 부분 (26) 을 검사하십시오 . 밀폐 부분
이 없어졌거나 손상된 경우 가까운 공인 수리 대리점
에 문의하십시오 . 본 제품을 사용하지 마십시오 .

호스 장착 (그림 K)

◆ 호스 (27) 의 클립 (28) 을 밀어 넣습니다 .

◆ 호스 (27) 를 스팀노즐 (4) 쪽으로 누르면서 클립을
놓습니다 .

중요 ! 소형 스팀 클리너를 사용하기 전에 호스 (27) 가
단단히 조여졌는지 확인하십시오 . 스팀이 이음부에서
빠져 호스가 정확하게 장착되지 않은 경우 , 기기를 식
힌 다음 호스를 분리했다가 다시 장착합니다 .

가변 스팀 분사 노즐 장착 (그림 L)

◆ 가변 스팀 분사 노즐 (31) 의 어느 쪽에 클립 (30) 을
밀어 넣습니다 .

◆ 가변 스팀 분사 노즐을 스팀 노즐 (4) 또는 호스 (27)
에 누르고 클립 (30) 을 해제합니다 .

중요 ! 소형 스팀 클리너를 사용하기 전에 가변 스팀 분
사 노즐 (31) 이 단단히 조여졌는지 확인하십시오 . 스
팀이 이음부에서 빠져서 가변 스팀 분사 노즐이 정확하
게 장착되지 않은 경우 , 기기를 식힌 다음 가변 스팀 분
사 노즐을 분리했다가 다시 장착합니다 .

기타 액세서리 장착 (그림 K)

◆ 호스의 레그를 액세서리의 우묵한 쪽에 맞춥니다 .

◆ 액세서리 (29) 를 호스 (27) 에 누르고 액세서리가 제
자리에 소리를 낼 때까지 시계 반대 방향으로 비틀어
돌립니다 .

참고 ! 가변 스팀 분사 노즐은 스팀 노즐에 직접 장착하
여 호스 없이 사용할 수 있습니다 . 기타 모든 액세서리
는 사용할 호스에 연결해야 합니다 .

호스 및 액세서리 분리 (그림 K & L)

경고 ! 사용 중에는 스팀 노즐 , 가변 스팀 분사 노즐 ,
호스 및 액세서리가 뜨거워질 수 있습니다 . 모든 액세
서리를 분리하기 전에 기기와 모든 액세서리의 열을 식
히십시오 .

액세서리 분리 (그림 K)

- ◆ 액세서리 (29) 를 시계 방향으로 비틀어 호스 (27) 에서 뺍니다.

호스 분리 (그림 K)

- ◆ 호스 (27) 의 어느 쪽에 클립 (29) 을 밀어 넣고 스팀 노즐 (4) 에서 떼어 놓습니다. 가변 스팀 분사 노즐 분리 (그림 L)
- ◆ 가변 스팀 분사 노즐 (31) 의 어느 쪽에 클립 (30) 을 밀어 넣고 스팀 노즐 (4) 에서 떼어 놓습니다.

사용법

중요! 이 기기는 본 설명서에 따라 사용하고 초극세사 패드를 부착하며 90 초 동안 연속 작동했을 때 세균과 미생물을 99.9% 살균할 것입니다.

전원 켜기 및 끄기 (스팀맵)

- ◆ 제품 스위치를 켜려면, ON/OFF 버튼 (1) 을 누릅니다. 스팀맵을 예열하려면 약 15 초가 걸립니다.

참고: 스팀맵을 처음 켜면, 물통이 빨간색으로 켜집니다. 스팀맵을 사용할 준비가 되면, 물통이 파란색으로 켜집니다.

- ◆ 제품 스위치를 끄려면, ON/OFF 버튼 (1) 을 누릅니다.

주의! 일정 기간 동안 스팀맵의 모든 표면에 얼룩이 남아 있도록 두지 마십시오. 항상 고정 시에는 수직 위치로 한 상태에서 스팀맵을 핸들 (10) 과 함께 놓고 사용하지 않을 때는 스팀맵이 꺼졌는지 확인하십시오.

주의! 항상 사용 후에는 물통을 비워주세요.

참고: 처음 물을 채웠거나 건조한 상태로 작동한 후에는 스팀이 생성되는 최대 45 초 걸릴 수 있습니다.

자동선택™ 기술 (그림 I)

이 스팀맵에는 다양한 청소 용도를 보여주는 자동선택™ 다이얼 (6) 이 장착되어 있습니다. 이를 사용하여 특정 청소를 위한 정확한 작동 모드를 선택합니다.

자동선택™을 사용하여, 필요한 설정이 선택될 때까지 자동선택 버튼 (6) 을 눌러서 다음 용도 중에서 하나를 선택합니다.

	목재 / 합판
	석재 / 대리석
	타일 / 비닐

스팀맵이 특정 청소를 위해 필요한 정확한 스팀 양을 선택합니다.

참고: 스팀맵을 사용하기 전에 정확한 설정으로 사용하고 있는지 확인하십시오. 사용하기 편하도록 스팀맵은 사용자의 최근 설정을 기억합니다.

강력스팀분사 (그림 H)

스팀맵에는 강력스팀분사 버튼 (25) 장착되어 있어 애기 힘든 자국과 오염 물질 제거 시 도움이 됩니다.

- ◆ 사용 중에는, 스팀 분사 버튼 (25) 을 눌러 추가로 청소능력을 강화시킵니다.

참고: 스팀 분사는 10 초간 지속되고, 스팀맵은 원래설정되었던 설정으로 돌아옵니다.

전원 켜기 및 끄기 (핸디형 스팀 청소기) (그림 M)

- ◆ 제품 스위치를 켜려면, ON/OFF 버튼 (1) 을 누릅니다. 핸디형 스팀 청소기를 예열하려면 약 15 초가 걸립니다.

참고: 핸디형 스팀 청소기를 처음 켜면, 물통이 빨간색으로 켜집니다. 핸디형 스팀 청소기를 사용할 준비가 되면, 물통이 파란색으로 켜집니다.

- ◆ 잠금 해제 스위치 (2) 를 올리고 방아쇠 스위치 (3) 를 당깁니다. 몇 초 후에 스팀이 만들어집니다.
- ◆ 제품 스위치를 끄려면, 방아쇠 스위치 (3) 를 놓은 다음 ON/OFF 버튼 (1) 을 누릅니다.

주의! 항상 사용 후에는 핸디형 스팀 청소기를 비우십시오.

주의! 방아쇠 스위치 (3) 에서 손을 뗀 후 잠깐 동안 스팀이 계속 만들어질 수 있는 데, 이는 정상입니다. 액세서리를 제거하기 전에 스위치를 끄고 기기의 열을 식히십시오.

최적의 사용법

일반 주의 사항

주의! 스팀맵 패드를 장착하지 않은 채 제품을 사용하지 마십시오.

- ◆ 사용하는 동안, 케이블 관리 클립 (17) 을 사용하여 케이블을 작업 영역 밖에 두십시오.
- ◆ 스팀맵을 사용하기 전에 항상 바닥을 진공 청소하거나 빗자루로 청소하십시오.
- ◆ 장치를 사용하는 가장 쉬운 방법은 핸들을 45 도로 기울여서 한 번에 적은 영역을 천천히 청소하는 것입니다.
- ◆ 스팀맵에 화학제품 클리너를 사용하지 마십시오. 비닐 또는 라놀륨 바닥에서 없애기 힘든 오염을 제거하려면, 스팀맵을 사용하기 전에 스팀 분사 버튼을 사

용하여 추가 스팀을 영역에 더하거나 증성 세제와 약간의 물로 사전 처리할 수 있습니다.

걸레를 사용한 스팀 청소

- ◆ 소형 스팀 클리너 (5) 를 스팀맷 본체 (9) 에 장착합니다.
- ◆ ‘고리’ 쪽이 위를 향하도록 한 상태에서 클리닝 패드 (12) 를 바닥에 놓으십시오.
- ◆ 스팀맷을 클리닝 패드 (12) 에 놓고 살짝 아래로 누릅니다.
- ◆ 스팀맷을 본체에 연결합니다.
- ◆ ON/OFF 버튼 (1) 을 누릅니다. 스팀맷을 예열하려면 약 15 초가 걸립니다.
- ◆ 오토셀렉트™ 버튼 (6) 을 눌러 필요한 설정에 놓습니다.
- ◆ 핸들 (10) 을 뒤로 당기면 스팀 펌프가 작동됩니다. 몇 초 후에 스팀 헤드에서 증기가 나오기 시작합니다.

참고: 처음 물을 채웠거나 건조한 상태로 작동한 후에는 스팀이 생성되는 최대 45 초 걸릴 수 있습니다.

- ◆ 스팀이 클리닝 패드에 들어가려면 몇 초가 걸립니다. 스팀맷은 살균 / 청소할 표면 위로 쉽게 미끄러집니다.
- ◆ 바닥에서 천천히 스팀맷을 끌어 당겨 모든 부분을 철저히 스팀 청소합니다.

참고: 사용하는 동안에는 핸들을 수직 위치로 복귀하여 스팀 펌프를 끌 수 있는데, 이러한 편리한 기능을 통해 스팀맷을 잠시 떠날 수 있어 제품을 끌 필요 없이 가구를 이동한 다음 청소를 계속할 수 있습니다.

- ◆ 스팀맷 사용을 마쳤으면, 핸들 (10) 을 수직 위치로 돌려 놓고 ‘OFF’ 로 바꾼 다음, 스팀맷이 식을 때까지 기다리십시오 (약 5 분).

주의! 물 탱크의 물 레벨을 모니터링하는 것이 중요합니다. 물 탱크를 보충하고 살균 / 청소를 계속하려면, 핸들 (10) 을 수직 위치로 돌려 놓고 스팀맷을 ‘OFF’ 로 바꿉니다. 전기 벽 콘센트에서 기기의 플러그를 뽑고, 물 탱크 (8) 를 다시 채웁니다.

주의! 일정 기간 동안 스팀맷의 모든 표면에 얼룩이 남아 있도록 두지 마십시오. 항상 고정 시에는 수직 위치로 한 상태에서 스팀맷을 핸들 (10) 과 함께 놓고 사용하지 않을 때는 스팀맷이 꺼졌는지 확인하십시오.

카펫청소하기 (FSMH1621S 는 해당없음)

- ◆ ‘고리’ 쪽이 위를 향하도록 한 상태에서 클리닝 패드 (12) 를 바닥에 놓으십시오.
- ◆ 스팀맷을 클리닝 패드 (12) 에 놓고 살짝 아래로 누릅니다.
- ◆ 카펫 글라이더 (14) 를 바닥에 놓습니다.
- ◆ 제 자리에 딱딱하고 소리가 날 때까지 스팀맷을 카펫

글라이더 (14) 에 놓고 살짝 누릅니다.

- ◆ 스팀맷을 본체에 연결합니다.
- ◆ ON/OFF 버튼 (1) 을 누릅니다. 스팀맷을 예열하려면 약 15 초가 걸립니다.
- ◆ 오토셀렉트™ 버튼 (6) 을 목재 / 합판 설정으로 누릅니다.
- ◆ 핸들 (10) 을 뒤로 당기면 스팀 펌프가 작동됩니다. 몇 초 후에 스팀 헤드에서 증기가 나오기 시작합니다.

참고: 처음 물을 채웠거나 건조한 상태로 작동한 후에는 스팀이 생성되는 최대 45 초 걸릴 수 있습니다.

- ◆ 카펫에서 천천히 스팀맷을 끌어 당겨 모든 부분을 철저히 리프레시합니다.

참고: 사용하는 동안에는 핸들을 수직 위치로 복귀하여 스팀 펌프를 끌 수 있는데, 이러한 편리한 기능을 통해 스팀맷을 잠시 떠날 수 있어 제품을 끌 필요 없이 가구를 이동한 다음 청소를 계속할 수 있습니다.

- ◆ 스팀맷 사용을 마쳤으면, 핸들 (10) 을 수직 위치로 돌려 놓고 ‘OFF’ 로 바꾼 다음, 스팀맷이 식을 때까지 기다리십시오 (약 5 분).

주의! 스팀이 핸디형 스팀 청소기와 스팀맷 본체 사이의 이음부에서 빠져 나오는 것이 보일 경우, 스위치를 끄고 기기를 메인 공급 장치에서 분리한 다음, 열을 식히십시오. 핸디형 스팀 청소기를 스팀맷 본체에서 분리합니다. 스팀 노즐 (4) 과 호스 (27) 의 밀봉 부분 (26) 을 검사하십시오 (그림 K). 밀폐 부분이 없어졌거나 손상된 경우 가까운 공인 수리 대리점에 문의하십시오. 본 제품을 사용하지 마십시오. 밀봉 부분의 상태가 좋을 경우, 제 자리에 단단히 안착되었는지 확인하면서 핸디형 스팀 청소기를 스팀맷 본체에 다시 장착합니다.

주의! 물 탱크의 물 레벨을 모니터링하는 것이 중요합니다. 물 탱크를 보충하고 살균 / 청소를 계속하려면, 핸들 (10) 을 수직 위치로 돌려 놓고 스팀맷을 ‘OFF’ 로 바꿉니다. 전기 벽 콘센트에서 기기의 플러그를 뽑고, 물 탱크 (8) 를 다시 채웁니다.

주의! 일정 기간 동안 스팀맷의 모든 표면에 얼룩이 남아 있도록 두지 마십시오. 항상 고정 시에는 수직 위치로 한 상태에서 스팀맷을 핸들 (10) 과 함께 놓고 사용하지 않을 때는 스팀맷이 꺼졌는지 확인하십시오.

사용 후 (그림 N 및 O)

- ◆ 핸들 (10) 을 똑바로 세우고 스팀맷을 끕니다.
- ◆ 스팀맷이 식을 때까지 기다리십시오 (약 5 분).
- ◆ 전기 벽 콘센트에서 스팀맷의 플러그를 뽑으십시오.
- ◆ 물 탱크 (8) 를 비우십시오.
- ◆ 스팀맷 패드 (12) 를 분리하여 다음 사용을 위해 닦아 놓으십시오. (클리닝 패드에 인쇄되어 있는 세척 관리 지침 사항을 준수하십시오).
- ◆ 케이블 정돈 길이 (15 및 16) 에 공급 케이블을 정리

합니다.

참고 : 상단 케이블 정돈 걸이 (16) 가 회전하여 다음에 케이블을 사용할 때 쉽게 준비할 수 있습니다 .

- ◆ 플러그 가까이에 있는 케이블 정돈 클립 (32) 을 사용하여 공급 케이블을 클립으로 고정합니다 .

참고 : 핸들 (10) 을 수직 위치로 하고, 케이블 정돈 걸이 (15 및 16) 주변으로 말끔하게 포장하고 케이블 정돈 클립 (32) 으로 고정하면 스팀맷이 보관 시 제힘으로 서 있게 됩니다 . 그 대신에 핸드 그림 (34) 에 장착되어 있는 벽걸이 브래킷 (33) 이 있어 스팀맷을 해당하는 벽고리에 걸 수 있습니다 . 항상 벽 걸이가 스팀맷의 무게를 안전하게 지탱할 수 있는지 확인하십시오 .

소형 스팀 클리닝

- ◆ 필요한 액세서리를 부착합니다 .
- ◆ 소형 스팀 클리너를 본체에 연결합니다 .
- ◆ ON/OFF 버튼 (1) 을 누릅니다 . 소형 스팀 클리너를 예열하려면 약 15 초가 걸립니다 .
- ◆ 잠금 해제 (2) 를 올리고 트리거 스위치 (3) 를 당겨 스팀 펌프를 작동시킵니다 . 몇 초 후에 스팀이 액세서리에서 나오기 시작합니다 .

참고 : 처음 물을 채웠거나 건조한 상태로 작동한 후에는 스팀이 생성되는 최대 45 초 걸릴 수 있습니다 .

참고 : 사용하는 동안에는 트리거 스위치에서 손을 떼서 스팀 펌프를 끌 수 있는데, 이러한 편리한 기능을 통해 잠깐 동안 소형 스팀 클리너를 아래에 놓을 수 있어 제품을 끌 필요 없이 가구의 품목을 이동한 다음 청소를 계속할 수 있습니다 .

- ◆ 소형 스팀 클리너를 다 사용했다면, 트리거 스위치 (3) 를 해제하고, 스위치를 끈 다음 메인 공급 장치에서의 연결을 끊습니다 . 보관하기 전에 스팀맷이 식을 때까지 기다리십시오 . (약 5 분)

주의 ! 물 탱크의 물 레벨을 모니터링하는 것이 중요합니다 . 물 탱크를 보충하고 살균 / 청소를 계속하려면, 핸디형 스팀 청소기를 'OFF' 로 바꿉니다 . 전기 벽 콘센트에서 기기의 플러그를 뽑고, 물 탱크 (8) 를 다시 채웁니다 .

주의 ! 방아쇠 스위치 (3) 에서 손을 뗀 후 잠깐 동안 스팀이 계속 만들어질 수 있는 데, 이는 정상입니다 . 액세서리를 제거하기 전에 스위치를 끄고 기기의 열을 식히십시오 .

액세서리

제품의 성능은 사용한 액세서리에 따라 결정됩니다 . BLACK+DECKER 액세서리는 높은 품질 기준을 만족하도록 제조되었으며, 제품의 성능을 향상시키도록 설계되었습니다 . 이러한 액세서리를 사용함으로써 제품의 기능을 최대한 활용할 수 있습니다 .

기술 데이터

		FSMH1621S1
전압	v.	220
전력	W	1600
탱크 용량	ml	350
무게	kg	3.6

문제 해결

제품이 제대로 작동하는 것 같지 않는 경우, 아래의 지침을 따르십시오 . 이렇게 해도 문제가 해결되지 않는 경우, 가까운 BLACK+DECKER 수리 대리점에 문의하십시오 .

문제	조치	가능한 해결책
스팀맷이 켜지지 않는다 .	1	기기의 플러그가 벽 콘센트에 잘 꽂혀 있는지 확인하십시오 .
	2	on/ off 스위치 (1) 를 사용하여 기기 스위치가 켜지는지 확인하십시오 .
	3	플러그의 퓨즈를 확인하십시오 .
디지털 제어장치가 켜지지 않는다 .	4	스팀맷의 핸들 (10) 이 스팀맷 본체 (9) 에 단단히 밀어 넣어졌는지 확인하십시오 . 핸들 (9) 의 화살표가 스팀맷 본체 (9) 의 상단과 수평을 이루는지 확인하십시오 .
	5	소형 스팀 클리너 (5) 가 스팀맷 본체 (9) 에 단단히 도킹되었는지 확인하십시오 .
	6	조치 1, 2 및 3 을 순서대로 확인하십시오 .
스팀맷에서 증기가 생성되지 않는다 .	7	핸들을 수직 위치에서 뒤로 당겨야만 스팀맷에서 증기가 생성됩니다 .
	8	물 탱크 (8) 가 가득 차 있는지 확인하십시오 . 참고 : 처음 물을 채웠거나 건조한 상태로 작동한 후에는 스팀이 생성되는 최대 45 초 걸릴 수 있습니다 .
	9	스팀 헤드 (11) 가 스팀맷 본체 (9) 에 단단히 도킹되었는지 확인하십시오 .
	10	조치 5, 1, 2 및 3 을 순서대로 확인하십시오 .
사용 중에 디지털 제어장치가 꺼진다 .	11	조치 4, 5, 1, 2 및 3 을 순서대로 확인하십시오 .
사용 중에 스팀맷의 스팀 생성이 멈춘다 .	12	조치 7, 8, 9, 5 및 3 을 순서대로 확인하십시오 .
사용 중에 스팀맷에서 너무 많은 스팀이 나온다 .	13	스팀맷에는 3 개의 설정이 있습니다 . 자동선택 버튼 (6) 을 눌러서 생성되는 스팀의 양을 줄이십시오 .
	14	스팀 분사 버튼 (25) 이 눌러지지 않았는지 확인하십시오 .
사용 중에 스팀맷에서 스팀이 너무 적게 나온다 .	15	스팀맷에는 3 개의 설정이 있습니다 . 자동선택 버튼 (6) 을 눌러서 생성되는 스팀의 양을 늘리십시오 .
	16	스팀 분사 버튼 (25) 을 눌러서 일시적으로 스팀의 양을 늘리십시오 .
트리거를 당기면 소형 스팀 클리너에서 스팀이 생성되지 않습니다 .	17	소형 스팀 클리너에는 락 오프 기능이 있습니다 . 잠금 해제 스위치 (2) 를 올리고 트리거 스위치 (3) 를 당깁니다 . 몇 초 후에 스팀이 만들어집니다 .
	18	조치 8, 1, 2 및 3 을 순서대로 확인하십시오 .
사용 중에 소형 스팀 클리너에서 스팀이 너무 적게 생성된다 .	19	소형 스팀 클리너는 15 초 후에 스팀을 생성하기 시작하고 45 초 후에 최대 스팀 용량에 도달합니다 .

문제	조치	가능한 해결책
소형 스팀 클리너가 스팀맷 본체에서 빠지지 않는다.	20	소형 스팀 클리너 탈착 버튼 (20) 을 단단히 누른 다음 소형 스팀 클리너 (5) 를 스팀맷 본체 (9) 에서 당겨 뺍니다 .
액세서리가 계속해서 기기에서 떨어진다.	21	모든 부품 및 액세서리의 정확한 장착 설명을 위해 설명서의 조립 장을 참조하십시오 .
기기의 예기치 않은 곳에서 스팀이 빠져 나온다.	22	모든 부품 및 액세서리의 정확한 장착 설명을 위해 설명서의 조립 장을 참조하십시오 .

환경 보호



분리 수거 . 본 제품을 일반 가정용 쓰레기로 처리하면 안됩니다 .

Black & Decker 제품을 교체해야 하거나 더 이상 쓸모가 없어졌다고 판단되면 본 제품을 가정용 쓰레기로 처리하지 마십시오 . 이 제품은 분리 수거하십시오 .



사용하던 제품과 포장을 분리 수거하면 자원을 재활용 및 재사용할 수 있습니다 . 재활용 자원을 이용하면 환경 오염이 방지되고 고철 자원에 대한 수요를 줄일 수 있습니다 .

지역에 따라 가정용 가전제품을 분리 수거하는 규정이 마련되어 있거나 새로운 제품을 구입할 때 판매점에서 폐기 방법을 알려줄 수 있습니다 .

서비스 정보

블랙앤드데커 청소기는 가까운 동부대우전자서비스 (1588-1588) 센터 (구 대우일렉서비스센터) 에서 받을 수 있습니다 . 모든 Black & Decker 서비스 센터에는 교육을 이수한 전문 직원이 배치되어 있어 고객에게 효과적이고 믿을 수 있는 전동 공구 서비스를 제공하고 있습니다 . 기술 지원 , 수리 또는 순정 교체 부품이 필요한 모든 경우에 가까운 Black & Decker 로 연락하십시오 .

참고

- ◆ Black & Decker 는 제품을 지속적으로 개선시키기 때문에 사전 통지 없이 제품 사양이 변경될 수 있습니다 .
- ◆ 기본 장비 및 액세서리 구성은 각 국가에 따라 다를 수 있습니다 .
- ◆ 제품 사양은 국가에 따라 다를 수 있습니다 .
- ◆ 국가에 따라 판매하지 않는 제품도 있을 수 있습니다 .
- ◆ 제품 판매 여부는 해당 지역에 있는 Black & Decker 판매점으로 문의하십시오 .